

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
ABARTH	595	3	15>	Smooth			
ABARTH	124 Spider		16>				
ACURA	ILX (DE1/2/3)	5	12>	Smooth	000126800000	000134700000	KIT19G
ACURA	MDX III (YD3)	5	14>	Smooth	000126900000	000134800000	KIT35G
ACURA	RDX I (TB1)	5	07>12	Smooth	000126800000	000134700000	KIT19G
ACURA	RDX II	5	13>18	Smooth	000126800000	000134700000	KIT35G
ACURA	RDX III	5	19>	Flush			
ACURA	RDX III	5	19>	Smooth	000126800000	000134700000	KIT35G
ACURA	TLX	4	15>19	Smooth	000126800000	000134700000	KIT15G
ACURA	TSX II (CU2) Sportwagon	5	11>14	Raised			
AIWAYS	U5		20>	Flush			
AIWAYS	U6	5	21>	Smooth	000126800000	000134700000	KIT76G
ALFA ROMEO	145		94>01				
ALFA ROMEO	146		96>01				
ALFA ROMEO	147	3	00>10	Smooth	000126700000	000134600000	KIT01G
ALFA ROMEO	147	5	00>10	Smooth	000126700000	000134600000	KIT02G
ALFA ROMEO	156	4	97>05	Smooth	000126700000	000134600000	KIT54G
ALFA ROMEO	159	4	05>13	Smooth	000126800000	000134700000	KIT03G
ALFA ROMEO	166	4	98>03	Smooth	000126700000	000134600000	KIT17G
ALFA ROMEO	156 Crosswagon	5	04>07	Raised			
ALFA ROMEO	156 Sportwagon	5	00>05	Raised			
ALFA ROMEO	156 Sportwagon	5	00>05	Smooth	000126700000	000134600000	KIT54G
ALFA ROMEO	159 Sportwagon	5	06>13	Raised			
ALFA ROMEO	159 Sportwagon	5	06>13	Smooth	000126700000	000134600000	KIT03G
ALFA ROMEO	Brera		06>11				
ALFA ROMEO	Brera S		08>11				
ALFA ROMEO	Giulia	4	16>	Smooth	000126700000	000134600000	KIT03G
ALFA ROMEO	Giulietta	5	10>	Smooth	000126700000	000134600000	KIT77G
ALFA ROMEO	GT	3	03>10				
ALFA ROMEO	GTV	2	98>03				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
ALFA ROMEO	JUNIOR	5	24>	Smooth	000126800000	000134700000	KIT41G
ALFA ROMEO	MiTo	3	08>16	Smooth			NA
ALFA ROMEO	MiTo	3	16>	Smooth			NA
ALFA ROMEO	Stelvio	5	17>	Flush			
ALFA ROMEO	Stelvio	5	17>	Smooth	000126800000	000134700000	KIT27G
ALFA ROMEO	Tonale (965)	5	22>	Smooth	000126800000	000134700000	KIT02G
AUDI	A1 (8X)	3	10>14	Smooth			NA
AUDI	A1 (8XA) Sportback	5	12>18	Smooth	000126700000	000134600000	KIT39G
AUDI	A1 (GB) Citycarver	5	19>	Smooth	000126700000	000134600000	KIT43G
AUDI	A1 (GB) Sportback	5	19>	Smooth	000126700000	000134600000	KIT49G
AUDI	A3 (8L)	5	96>03	Smooth	000126700000	000134600000	KIT36G
AUDI	A3 (8P)	3	04>12	Smooth	000126700000	000134600000	KIT01G
AUDI	A3 (8P7) Cabrio		08>13				
AUDI	A3 (8PA) Sportback	5	04>12	Flush			
AUDI	A3 (8PA) Sportback	5	04>12	Smooth	000126700000	000134600000	KIT19G
AUDI	A3 (8V)	3	13>19	Smooth			NA
AUDI	A3 (8V) Cabrio		13>19				
AUDI	A3 (8VA) Sportback	5	13>20	Flush			
AUDI	A3 (8VA) Sportback	5	13>20	Smooth	000126700000	000134600000	KIT10G
AUDI	A3/S3 (8V) Sedan	4	13>19	Smooth	000126700000	000134600000	KIT03G
AUDI	A3 (8Y) Sportback	5	20>	Flush			
AUDI	A3 (8Y) Sportback	5	20>	Smooth	000126800000	000134700000	KIT48G
AUDI	A4 (B5/8D)	4	94>00	Smooth	000126700000	000134600000	KIT13G
AUDI	A4 (B5/8D) Avant	5	94>00	Raised			
AUDI	A4 (B6/8E/8H)	4	00>04	Smooth	000126700000	000134600000	KIT36G
AUDI	A4 (B6/8E/8H) Avant	5	00>04	Raised			
AUDI	A4 (B7/8E/8H)	4	04>07	Smooth	000126700000	000134600000	KIT36G
AUDI	A4 (B7/8E/8H) Avant	5	04>07	Raised			
AUDI	A4 (B8/8K)	4	07>12	Smooth	000126700000	000134600000	KIT36G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
AUDI	A4 (B8/8K)	4	12>15	Smooth	000126800000	000134700000	KIT29G
AUDI	A4 (B8/8K) Allroad	5	07>15	Raised			
AUDI	A4 (B8/8K) Avant	5	07>15	Flush			
AUDI	A4 (B9/8W)	4	15>19	Smooth	000126800000	000134700000	KIT03G
AUDI	A4 (B9/8W)	4	19>	Smooth	000126800000	000134700000	KIT03G
AUDI	A4 (B9/8W) Allroad	5	15>	Raised			
AUDI	A4 (B9/8W) Avant	5	15>	Flush			
AUDI	A5 (8F7) Cabrio		09>16				
AUDI	A5 (8T)	5	16>	Smooth			NA
AUDI	A5 (8T3) Coupé		14>				
AUDI	A5 (8TA) Sportback	5	16>	Smooth			NA
AUDI	A5 (8TA) Sportback		07>16				
AUDI	A5 (F5)	5	16>	Smooth			NA
AUDI	A6 (4B/C5) Allroad		99>05	Raised			
AUDI	A6 (4B/C5) Avant		97>04	Raised			
AUDI	A6 (4F/C6)	4	04>11	Smooth	000126800000	000134700000	KIT36G
AUDI	A6 (4F/C6) Allroad	5	06>11	Raised			
AUDI	A6 (4F/C6) Avant	5	04>11	Flush			
AUDI	A6 (4G/C7)	4	11>18	Smooth			NA
AUDI	A6 (4G/C7) Allroad	5	12>14	Raised			
AUDI	A6 (4G/C7) Allroad	5	14>18	Raised			
AUDI	A6 (4G/C7) Avant	5	11>15	Flush			
AUDI	A6 (4G/C7) Avant	5	15>18	Flush			
AUDI	A6 (4A/C8)	4	18>	Smooth	000126800000	000134700000	KIT26G
AUDI	A6 (4A/C8) Avant	5	18>	Flush			
AUDI	A7 (4G/C7) Sportback	4	10>18	Smooth			NA
AUDI	A7 (C8/4K) Sportback	4	18>	Smooth			NA
AUDI	A8 (D2/4D)		94>02				
AUDI	A8 (D3/4E)		02>09				
AUDI	A8 (D4/4H)	4	09>13	Smooth			NA

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
AUDI	A8 (D4/4H)	4	14>17	Smooth			NA
AUDI	A8 (D5/4N)	4	17>	Smooth	000126800000	000134700000	KIT48G
AUDI	E-TRON Sportback	5	21>	Smooth	000126800000	000134700000	KIT04G
AUDI	Q2 (GA)	5	16>	Smooth	000126800000	000134700000	KIT26G
AUDI	Q3 (8U)	5	11>18	Flush			
AUDI	Q3 (F3)	5	18>	Flush			
AUDI	Q3 (F3) Sportback	5	19>	Smooth	000126800000	000134700000	KIT36G
AUDI	Q4 E TRON	5	21>	Flush			
AUDI	Q5 (8R)	5	08>16	Flush			
AUDI	Q5 (FY)	5	17>	Flush			
AUDI	Q5 (FYT) Sportback	5	21>	Smooth	000126800000	000134700000	KIT04G
AUDI	Q7 (4L)	5	05>15	Flush			
AUDI	Q7 (4M)	5	15>				
AUDI	Q8 (4M)	5	18>	Flush			
AUDI	Q8 E TRON	5	22>	Flush			
AUDI	S3 Sportback	5	13>				
AUDI	S5 Sportback	4	11>	Smooth			NA
AUDI	S8		15>				
AUDI	TT (8J)		06>14				
AUDI	TT (8J) RS		10>				
AUDI	TT (8N)		98>06				
AUDI	TT (8N) Roadster		98>06				
AUDI	TT (8S)		14>				
AUDI	TT (8S) Roadster		14>				
AUDI	TTs (8S) Coupè		14>				
BMW	i3 (I01)		13>				NA
BMW	i8		14>				
BMW	IX (I20)	5	21>	Smooth	000126800000	000134700000	FIX204FP
BMW	IX1 (U11)	5	22>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
BMW	IX2 (U10)	5	24>	Smooth	000126800000	000134700000	KIT02G
BMW	M2 (F87) Coupé	2	17>	Smooth	000126800000	000134700000	FIX201FP
BMW	Serie 1 (E81)	3	07>11	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (E82) Coupé	2	07>13				
BMW	Serie 1 (E87)	5	04>11	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (F20)	5	11>15	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (F20)	5	15>19	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (F21)	3	12>15	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (F21)	3	15>19	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 1 (F40)	5	19>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 2 (F22) Coupé	2	14>21	Smooth	000126800000	000134700000	FIX201FP
BMW	Serie 2 (G42) Coupé	3	21>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 2 (F23) Cabrio	2	15>				
BMW	Serie 2 (F45) Active Tourer	5	14>21	Flush			
BMW	Serie 2 (F45) Active Tourer	5	14>21	Smooth	000126800000	000134700000	KIT03G
BMW	Serie 2 (U06) Active Tourer	5	21>	Smooth	000126800000	000134700000	KIT02G
BMW	Serie 2 (F44) Gran Coupé	5	19>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 2 (F46) Gran Tourer	5	15>	Flush			
BMW	Serie 2 (F46) Gran Tourer	5	15>	Smooth	000126800000	000134700000	KIT38G
BMW	Serie 3 (E36)		90>00				
BMW	Serie 3/M3 (E46)	4	98>07	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (E46/3) Touring		99>05	Raised			
BMW	Serie 3 (E90)	4	05>12	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (E91) Touring	5	05>12	Raised			
BMW	Serie 3 (E91) Touring	5	05>12	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (E92) Coupé	2	05>13	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (E93) Cabrio		05>13				
BMW	Serie 3 (F30)	4	12>15	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (F30)	4	15>18	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 3 (F31) Touring	5	12>15	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
BMW	Serie 3 (F31) Touring	5	15>18	Flush			
BMW	Serie 3 (F31) Touring	5	12>15	Smooth			NA
BMW	Serie 3 (F31) Touring	5	15>18	Smooth			NA
BMW	Serie 3 (F34) GT	5	13>18				
BMW	Serie 3 (G20)	4	19>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 3 (G21) Touring	5	19>	Flush			
BMW	Serie 4 (F32) Coupé	3	13>20	Smooth			NA
BMW	Serie 4 (G22) Coupé	3	20>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 4 (F33) Cabrio	2	14>18				
BMW	Serie 4 (F36) Gran Coupé	4	13>20	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 4 (G26) Gran Coupé	5	20>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 5 (E39)	4	95>03	Smooth	000126700000	000134600000	FIX201FP
BMW	Serie 5 (E39) Touring		95>04	Raised			
BMW	Serie 5 (E61) Touring	5	03>10	Raised			
BMW	Serie 5 (E61) Touring	5	03>10	Smooth	000126800000	000134700000	KIT02G
BMW	Serie 5 (G60)	4	24>	Smooth	000126800000	000134700000	FIX204FP
BMW	Serie 5 (G61) Touring	5	24>	Flush			
BMW	Serie 5 (F07) GT	4	09>17	Smooth	000126800000	000134700000	FIX203FP
BMW	Serie 5 (F10)	4	10>16	Smooth	000126800000	000134700000	FIX204FP
BMW	Serie 5 (F11) Touring	5	10>16	Flush			
BMW	Serie 5 (F11) Touring	5	10>16	Smooth	000126800000	000134700000	KIT03G
BMW	Serie 5 (G30)	4	17>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 5 (G31) Touring	5	17>	Flush			
BMW	Serie 5 (G31) Touring	5	17>	Smooth	000126800000	000134700000	KIT02G
BMW	Serie 6 (E64) Coupé		04>11				
BMW	Serie 6 (F06) Gran Coupé		12>				
BMW	Serie 6 (F12) Cabrio	2	10>19				
BMW	Serie 6 (F13) Coupé	2	10>15				
BMW	Serie 6 (G32) GT	5	17>	Smooth	000126800000	000134700000	FIX201FP
BMW	Serie 7 (E38)		94>01				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
BMW	Serie 7 (E65)		01>08				
BMW	Serie 7 (F01)		08>15				
BMW	Serie 7 (G11)	4	15>	Smooth	000126800000	000134700000	FIX204FP
BMW	Serie 8 (G15)	2	18>	Smooth	000126700000	000134600000	FIX204FP
BMW	Serie 8 (G16) Gran Coupé	4	19>	Smooth	000126700000	000134600000	FIX204FP
BMW	X1 (E84)	5	09>12	Flush			
BMW	X1 (E84)	5	12>15	Flush			
BMW	X1 (E84)	5	09>12	Smooth	000126800000	000134700000	KIT10G
BMW	X1 (E84)	5	12>15	Smooth	000126800000	000134700000	KIT10G
BMW	X1 (F48)	5	15>19	Flush			
BMW	X1 (F48)	5	19>	Flush			
BMW	X1 (F48)	5	15>19	Smooth	000126800000	000134700000	KIT08G
BMW	X1 (F48)	5	19>	Smooth	000126800000	000134700000	KIT02G
BMW	X2 (F39)	5	18>23	Smooth	000126800000	000134700000	KIT02G
BMW	X2 (U10)	5	23>	Smooth	000126800000	000134700000	KIT02G
BMW	X3 (E83)	5	04>10	Raised			
BMW	X3 (E83)	5	04>10	Smooth	000126800000	000134700000	KIT10G
BMW	X3 (F25)	5	10>17	Flush			
BMW	X3 (F25)	5	10>17	Smooth	000126800000	000134700000	KIT08G
BMW	X3 (G01)		17>	Flush			
BMW	X3 (G45)	5	24>	Flush			
BMW	X4 (F26)	5	14>18	Flush			
BMW	X4 (F26)	5	14>18	Smooth	000126800000	000134700000	KIT27G
BMW	X4 (G02)	5	18>	Flush			
BMW	X4 (G02)	5	18>	Smooth	000126800000	000134700000	KIT49G
BMW	X5 (E53)		99>06	Raised			
BMW	X5 (E70)		06>10	Raised			
BMW	X5 (E70)		10>13	Raised			
BMW	X5 (F15)	5	13>18	Flush			
BMW	X5 (F15)	5	13>18	Smooth	000126800000	000134700000	KIT02G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
BMW	X5 (G05)	5	19>	Flush			
BMW	X5 (G05)	5	19>	Smooth	000126800000	000134700000	KIT02G
BMW	X6 (E71)	5	07>14	Raised			
BMW	X6 (E71)	5	07>14	Smooth	000126800000	000134700000	KIT27G
BMW	X6 (F16)	5	14>	Smooth	000126800000	000134700000	KIT27G
BMW	X7 (G07)	5	18>	Raised			
BMW	Z3		95>02				
BMW	Z4 (E86) Coupè		02>08				
BMW	Z4 (E89)		09>16				
BYD	Dolphin	5	21>	Smooth	000126800000	000134700000	KIT76G
BYD	Sealion 7	5	24>	Smooth	000126800000	000134700000	KIT78G
BYD	Seal U	5	23>	Flush			
CITROEN	Berlingo (Mk1) / Berlingo (Mk1) Van	5	96>10	Raised			
CITROEN	Berlingo (Mk1) / Berlingo (Mk1) Van	5	96>10	Smooth	000126700000	000134600000	KIT24G
CITROEN	Berlingo II (B9) / Berlingo II (B9)Van / Berlingo II (B9) XTR	5	08>18	Raised			
CITROEN	Berlingo II (B9) / Berlingo II (B9)Van / Berlingo II (B9) XTR	5	08>18	Smooth	000126800000	000134700000	FIX207FP
CITROEN	Berlingo III / Berlingo III XL	5	18>	Raised			
CITROEN	Berlingo III / Berlingo III XL	5	18>	Smooth	000126800000	000134700000	FIX207FP
CITROEN	C1	3	12>14	Smooth			NA
CITROEN	C1	5	14>	Smooth	000126700000	000134600000	KIT17G
CITROEN	C1	5	05>14	Smooth	000126700000	000134600000	KIT17G
CITROEN	C2		03>09				
CITROEN	C3 (Mk1)	5	01>10	Raised			
CITROEN	C3 (Mk1)	5	01>10	Smooth			NA
CITROEN	C3 (Mk2)	5	09>13	Smooth			NA
CITROEN	C3 (Mk2)	5	13>15	Smooth			NA
CITROEN	C3 (Mk2) Picasso	5	08>17	Raised			
CITROEN	C3 (Mk2) Picasso	5	08>17	Smooth			NA

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
CITROEN	C3 (Mk3)	5	16>23	Smooth	000126700000	000134600000	KIT47G
CITROEN	C3 (Mk3) plastic railing	5	24>	Flush	000126800000	000134700000	KIT45G
CITROEN	C3	5	24>	Smooth	000126800000	000134700000	KIT45G
CITROEN	C3 (Mk3) Aircross	5	17>23	Raised			
CITROEN	C3 (Mk3) Aircross	5	17>23	Smooth	000126800000	000134700000	KIT26G
CITROEN	C3 Aircross	5	24>	Smooth	000126800000	000134700000	KIT90G
CITROEN	C3 Xtr		04>10	Raised			
CITROEN	C4	5	04>10	Smooth	000126700000	000134600000	FIX201FP
CITROEN	C4	5	10>18	Smooth	000126800000	000134700000	KIT07G
CITROEN	C4 (Mk3)	5	20>	Smooth	000126800000	000134700000	KIT48G
CITROEN	C4 Aircross	5	12>	Flush			
CITROEN	C4 Aircross	5	12>	Smooth	000126800000	000134700000	FIX203FP
CITROEN	C4 Cactus	5	18>20	Flush			
CITROEN	C4 Cactus		14>18	Flush			
CITROEN	C4 Cactus	5	18>20	Smooth	000126700000	000134600000	KIT11G
CITROEN	C4 Picasso (Mk1)	5	06>13	Raised			
CITROEN	C4 Picasso (Mk1)	5	06>13	Smooth	000126800000	000134700000	FIX201FP
CITROEN	C4 Picasso (Mk2)	5	13>18	Smooth	000126800000	000134700000	KIT41G
CITROEN	C4 Grand Picasso (Mk1)		06>13	Raised			
CITROEN	C4 Grand Picasso (Mk2)	5	13>18	Smooth	NA	NA	NA
CITROEN	C4 Spacetourer (Mk2)	5	18>22	Smooth	000126800000	000134700000	KIT41G
CITROEN	C4 Grand Spacetourer (Mk2)	5	18>22	Smooth	NA	NA	NA
CITROEN	C4X/e C4X (E43)	5	22>	Smooth	000126800000	000134700000	KIT48G
CITROEN	C5 (Mk1)	4	00>07	Smooth	000126700000	000134600000	KIT10G
CITROEN	C5 (Mk1) Tourer	5	00>07	Raised			
CITROEN	C5 (Mk2)	4	07>17	Smooth	000126700000	000134600000	FIX201FP
CITROEN	C5 (Mk2) Cross Tourer	5	14>17	Raised			
CITROEN	C5 (Mk2) Tourer	5	07>17	Raised			
CITROEN	C5 Aircross	5	17>	Raised			
CITROEN	C5 X (E43)	5	21>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
CITROEN	C5 X (E43)	5	21>	Smooth	000126800000	000134700000	KIT48G
CITROEN	C6	4	05>12	Smooth	000126700000	000134600000	FIX205FP
CITROEN	C8		02>14				
CITROEN	C-Crosser		07>12	Raised			
CITROEN	C-Elysee	4	12>	Smooth			NA
CITROEN	C-Zero	5	10>	Smooth	000126700000	000134600000	KIT10G
CITROEN	Ds3		10>15	Smooth			NA
CITROEN	Ds4	5	11>15	Smooth	000126800000	000134700000	KIT27G
CITROEN	Ds5	5	11>15	Smooth	000126800000	000134700000	KIT27G
CITROEN	Evasion		94>02				
CITROEN	Jumpy (Mark1)		94>07	Smooth	000126800000	000134700000	FIX208FP
CITROEN	Jumpy (Mark2)		07>16	Smooth	000126800000	000134700000	FIX208FP
CITROEN	Nemo		08>	Raised			
CITROEN	Nemo		08>	Smooth	000126800000	000134700000	FIX208FP
CITROEN	Nemo Van		08>	Raised			
CITROEN	Nemo Van		08>	Smooth	000126800000	000134700000	FIX208FP
CITROEN	Saxo	5	96>04	Smooth	000126700000	000134600000	KIT13G
CITROEN	Xantia		93>02				
CITROEN	Xm		94>00				
CITROEN	Xm Break		94>00	Raised			
CITROEN	Xsara	5	97>06	Smooth	000126700000	000134600000	KIT22G
CITROEN	Xsara Break		97>06				
CITROEN	Xsara Picasso	5	99>10	Smooth	000126700000	000134600000	KIT24G
CUPRA	Ateca	5	18>	Raised			
CUPRA	Born	5	24>	Smooth	000126800000	000134700000	KIT02G
CUPRA	Formentor	5	20>24	Raised			
CUPRA	Formentor	5	24>	Raised			
CUPRA	Leon IV (MK4) (No tetto in vetro / No glass sunroof)	5	20>23	Smooth	000126800000	000134700000	KIT02G
CUPRA	Leon IV (MK4) Sporturer (No tetto in vetro / No glass sunroof)	5	20>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
CUPRA	Leon	5	24>	Smooth	000126800000	000134700000	KIT89G
CUPRA	Tavascan	5	24>	Smooth	000126800000	000134700000	KIT45G
CUPRA	Terramar	5	24>	Flush			
DACIA	Dokker		12>	Raised			
DACIA	Duster I		08>13	Raised			
DACIA	Duster I		13>18	Raised			
DACIA	Duster II		18>24	Raised			
DACIA	Duster III		24>	Raised			
DACIA	Duster Oroch		16>	Raised			
DACIA	Jogger	5	21>	Raised			
DACIA	Lodgy		12>	Flush			
DACIA	Logan	4	04>12	Smooth	000126800000	000134700000	KIT70G
DACIA	Logan MCV		04>13	Raised			
DACIA	Logan MCV		13>	Raised			
DACIA	Sandero	5	08>12	Smooth	000126700000	000134600000	KIT70G
DACIA	Sandero	5	13>20	Smooth	000126700000	000134600000	KIT70G
DACIA	Sandero	5	21>	Smooth	000126800000	000134700000	KIT86G
DACIA	Sandero Stepway		09>12	Raised			
DACIA	Sandero Stepway		13>20	Raised			
DACIA	Sandero Stepway		21>	Raised			
DACIA	Sandero Stepway	5	24>	Raised			
DACIA	Spring	4	21>	Flush			NA
DAEWOO	Lacetti		02>11				
DAEWOO	Leganza		97>02				
DAEWOO	Matiz	5	98>07	Raised			
DAEWOO	Matiz	5	98>07	Smooth	000126700000	000134600000	KIT17G
DAEWOO	Nexsia		94>				
DAEWOO	Nubira		97>03	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
DAEWOO	Nubira (J200) Station Wagon		02>09	Raised			
DAEWOO	Nubira Station Wagon		97>03	Raised			
DAEWOO	Rezzo		00>08	Raised			
DAEWOO	Tacuma		00>04	Raised			
DAIHATSU	Charade	5	11>13	Smooth	000126700000	000134600000	KIT17G
DAIHATSU	Cuore	5	07>	Smooth	000126700000	000134600000	KIT02G
DAIHATSU	Materia	5	06>16	Smooth	000126800000	000134700000	KIT18G
DAIHATSU	Sirion (M100)		98>04				
DAIHATSU	Sirion (M300)	5	04>11	Smooth	000126800000	000134700000	KIT17G
DAIHATSU	Terios (J100)	5	97>06				
DAIHATSU	Terios II (J200/F700)	5	06>17	Raised			
DAIHATSU	Terios II (J200/F700)	5	06>17	Smooth	000126700000	000134600000	KIT19G
DAIHATSU	Terios III (F800)	5	17>	Flush			
DAIHATSU	Trevis		04>10				
DAIHATSU	Xenia		03>11	Raised			
DAIHATSU	Xenia		11>	Raised			
DAIHATSU	Yrv		00>05				
FIAT	500/500e/500EV/500 Hybrid (312/332)	3	07>	Smooth	000126700000	000134600000	KIT12G
FIAT	600		05>10				
FIAT	600	5	24>	Smooth	000126800000	000134700000	KIT41G
FIAT	124 Spider		16>				
FIAT	500 Abarth		07>14				
FIAT	500 C		09>15				
FIAT	500 C		15>				
FIAT	500 GQ	3	13>	Smooth			NA
FIAT	500 L	5	12>	Smooth	000126800000	000134700000	KIT43G
FIAT	500 L Living	5	13>	Smooth	000126800000	000134700000	KIT43G
FIAT	500 L Trekking	5	13>	Smooth	000126800000	000134700000	KIT43G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FIAT	500 X	5	15>	Flush			
FIAT	500 X	5	15>	Smooth	000126800000	000134700000	KIT08G
FIAT	Brava	5	95>01	Smooth	000126700000	000134600000	KIT08G
FIAT	Bravo	3	95>01	Smooth	000126700000	000134600000	KIT09G
FIAT	Bravo	5	07>14	Smooth	000126800000	000134700000	KIT10G
FIAT	Coupe		94>00				
FIAT	Croma	5	05>10	Raised			
FIAT	Croma	5	05>10	Smooth	000126700000	000134600000	FIX202FP
FIAT	Doblò		00>10	Raised			
FIAT	Doblò Cargo / Cargo Maxi		00>10	Smooth	000126800000	000134700000	FIX208FP
FIAT	Doblò II	5	10>22	Raised			
FIAT	Doblò II	5	10>22	Smooth	000126800000	000134700000	FIX208FP
FIAT	Doblò II Maxi	5	10>22	Raised			
FIAT	Doblò II Maxi	5	10>22	Smooth	000126800000	000134700000	FIX208FP
FIAT	Doblò III/e Doblò III (K9)	5	22>	Raised			
FIAT	Doblò Malibù		00>05	Raised			
FIAT	Doblò Restyling		09>10	Smooth	000126700000	000134600000	KIT53G
FIAT	Fiorino II		87>13	Smooth	000126800000	000134700000	FIX208FP
FIAT	Fiorino III		07>	Raised			
FIAT	Fiorino III		07>	Smooth	000126800000	000134700000	FIX208FP
FIAT	Freemont	5	11>	Raised			
FIAT	Freemont	5	11>	Smooth	000126800000	000134700000	KIT06G
FIAT	Freemont Cross		14>	Raised			
FIAT	Fullback	4	15>	Smooth	000126800000	000134700000	KIT12G
FIAT	Grande Punto (199)	3	05>12	Smooth	000126700000	000134600000	KIT05G
FIAT	Grande Punto (199)	5	05>12	Smooth	000126700000	000134600000	KIT02G
FIAT	Idea	5	05>12	Raised			
FIAT	Idea	5	05>12	Smooth	000126700000	000134600000	FIX203FP
FIAT	Marea	4	96>03	Smooth	000126700000	000134600000	KIT08G
FIAT	Marea Weekend		96>03	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FIAT	Marengo		97>01	Raised			
FIAT	Multipla	5	98>03	Smooth	000126900000	000134800000	FIX206FP
FIAT	Multipla II	5	04>10	Smooth	000126900000	000134800000	FIX206FP
FIAT	Palio Weekend		97>01	Raised			
FIAT	Panda II (169)	5	03>12	Raised			
FIAT	Panda II (169)	5	03>12	Smooth	000126700000	000134600000	KIT08G
FIAT	Panda II (169) Cross		04>14	Raised			
FIAT	Panda II (169) Trekking		03>12				
FIAT	Panda III (319)	5	12>	Flush			
FIAT	Panda III (319)	5	12>	Smooth	000126800000	000134700000	KIT02G
FIAT	Panda III (319) (Fixed Point)	5	15>	Smooth	000126700000	000134600000	FIX203FP
FIAT	Panda III (319) AirCross	5	14>	Raised			
FIAT	Panda III (319) City Cross	5	17>	Flush			
FIAT	Panda III (319) Cross	5	14>	Raised			
FIAT	Panda III (319) Hybrid	5	20>	Flush			
FIAT	Panda III (319) Trussardi	5	20>	Raised			
FIAT	Punto Evo (199)	3	09>12	Smooth	000126700000	000134600000	KIT05G
FIAT	Punto Evo (199)	5	09>12	Smooth	000126700000	000134600000	KIT02G
FIAT	Punto I (176)	3	93>99	Smooth	000126700000	000134600000	KIT56G
FIAT	Punto I (176)	5	93>99	Smooth	000126700000	000134600000	KIT55G
FIAT	Punto II (188)	3	99>07	Smooth	000126700000	000134600000	KIT57G
FIAT	Punto II (188)	5	99>07	Smooth	000126700000	000134600000	KIT58G
FIAT	Punto II Classic (188)	3	07>10	Smooth	000126700000	000134600000	KIT57G
FIAT	Punto II Classic (188)	5	07>10	Smooth	000126700000	000134600000	KIT58G
FIAT	Punto III (199)	3	12>18	Smooth	000126700000	000134600000	KIT05G
FIAT	Punto III (199)	5	12>18	Smooth	000126700000	000134600000	KIT02G
FIAT	Qubo	5	07>	Raised			
FIAT	Qubo	5	07>	Smooth	000126800000	000134700000	FIX208FP
FIAT	Scudo	5	94>06	Smooth	000126800000	000134700000	FIX208FP
FIAT	Scudo II	5	07>16	Smooth			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FIAT	Sedici	5	05>14	Raised			
FIAT	Seicento		98>05				
FIAT	Stilo	3	01>10	Smooth	000126700000	000134600000	FIX202FP
FIAT	Stilo	5	01>10	Smooth	000126700000	000134600000	FIX202FP
FIAT	Stilo Station Wagon		01>10	Raised			
FIAT	Strada IV		09>	Raised			
FIAT	Tipo	4	15>	Smooth	000126800000	000134700000	KIT87G
FIAT	Tipo Cross	5	20>	Flush			
FIAT	Tipo Hatchback	5	16>	Smooth	000126800000	000134700000	KIT45G
FIAT	Tipo Station Wagon	5	16>	Flush			
FIAT	Tipo Station Wagon	5	16>	Smooth	000126800000	000134700000	KIT76G
FIAT	Toro	4	16>	Raised			
FIAT	Ulysse	5	02>10	Smooth			NA
FIAT	Ulysse		94>02				
FORD	B-Max	5	12>18	Flush			
FORD	B-Max	5	12>18	Smooth	000126800000	000134700000	KIT37G
FORD	Bronco (U275)	5	22>	Raised			
FORD	Bronco (U275)	5	22>	Smooth	NA	NA	NA
FORD	C-Max	5	03>10	Smooth	000126700000	000134600000	FIX201FP
FORD	C-Max 7 II / Grand C-Max	5	10>	Raised			
FORD	C-Max 7 II / Grand C-Max	5	10>	Smooth			NA
FORD	C-Max II	5	10>19	Raised			
FORD	C-Max II	5	10>19	Smooth	000126800000	000134700000	KIT08G
FORD	Connect I Transit		02>13	Smooth	000126800000	000134700000	FIX208FP
FORD	Cougar		98>02				
FORD	Ecosport	5	14>17		000126700000	000134600000	KIT04G
FORD	Ecosport	5	17>		000126700000	000134600000	KIT04G
FORD	Edge	5	16>	Flush			
FORD	Edge		06>10	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FORD	Edge	5	16>	Smooth	000126800000	000134700000	KIT08G
FORD	Escape II	5	08>12	Raised			
FORD	Escape III (C520)	5	13>19	Raised			
FORD	Escape III (C520)	5	13>19	Smooth	000126800000	000134700000	KIT29G
FORD	Escort IV		95>00				
FORD	Escort IV Station Wagon		90>00	Raised			
FORD	Everest		03>15	Raised			
FORD	Everest		15>	Raised			
FORD	Explorer	4	02>05	Raised			
FORD	Explorer III (U502)	5	11>19				
FORD	F150 SuperCab	2	15>20	Smooth	000126900000	000134800000	KIT19G
FORD	F150 SuperCrew Cab	4	15>20	Smooth	000126900000	000134800000	KIT19G
FORD	F150 XIV Crew Cab	4	22>	Smooth	000126900000	000134800000	KIT19G
FORD	F250	4	15>	Smooth	000126900000	000134800000	KIT19G
FORD	Fiesta IV	5	96>02	Smooth	000126700000	000134600000	KIT13G
FORD	Fiesta V	3	02>08	Smooth	000126800000	000134700000	KIT15G
FORD	Fiesta V	5	02>08	Smooth	000126700000	000134600000	KIT16G
FORD	Fiesta VI	3	08>17	Smooth			NA
FORD	Fiesta VI	5	13>17	Smooth	000126700000	000134600000	KIT03G
FORD	Fiesta VI	5	08>13	Smooth	000126700000	000134600000	KIT19G
FORD	Fiesta VII	3	17>	Smooth			NA
FORD	Fiesta VII	5	17>	Smooth	000126700000	000134600000	KIT03G
FORD	Fiesta VII Active	5	18>	Flush			
FORD	Fiesta VII ST-Line	5	17>	Smooth	000126700000	000134600000	KIT03G
FORD	Flex	5	13>	Smooth	000126900000	000134800000	KIT08G
FORD	Focus I	5	98>05	Smooth	000126700000	000134600000	KIT36G
FORD	Focus I Station Wagon	5	98>05	Raised			
FORD	Focus I Station Wagon	5	98>05	Smooth	000126700000	000134600000	KIT36G
FORD	Focus II	5	04>11	Smooth	000126700000	000134600000	FIX201FP
FORD	Focus II Station Wagon (Fix Point)	5	04>11	Smooth	000126700000	000134600000	FIX201FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FORD	Focus II Station Wagon (No Fix Point)	5	04>11	Smooth	000126800000	000134700000	KIT02G
FORD	Focus II Station Wagon (Raised Rails)	5	04>11	Raised			
FORD	Focus III	5	11>18	Smooth	000126800000	000134700000	KIT36G
FORD	Focus III ST		14>18				
FORD	Focus III Station Wagon	5	11>18	Flush			
FORD	Focus III Station Wagon	5	11>18	Smooth	000126800000	000134700000	KIT10G
FORD	Focus IV	5	18>	Smooth	000126800000	000134700000	KIT48G
FORD	Focus IV Active	5	19>	Flush			
FORD	Focus IV Wagon	5	18>	Flush			
FORD	Freestyle		05>07	Raised			
FORD	Fusion	5	02>12	Smooth	000126700000	000134600000	KIT16G
FORD	Fusion Sedan II	4	13>	Smooth	000126800000	000134700000	KIT36G
FORD	F-Series	4	21>	Smooth	000126900000	000134800000	KIT17G
FORD	Galaxy I		99>05	Raised			
FORD	Galaxy II		06>15	Flush			
FORD	Galaxy III		15>	Flush			
FORD	Ka		96>08				
FORD	Ka +	5	16>	Smooth	000126700000	000134600000	KIT13G
FORD	Ka + Active	5	18>	Flush			
FORD	Ka II		08>16				
FORD	Kuga	5	08>12	Raised			
FORD	Kuga II (C520)	5	12>20	Raised			
FORD	Kuga II (C520)	5	12>20	Smooth	000126800000	000134700000	KIT28G
FORD	Kuga III/Escape IV (no tetto in vetro)	5	20>	Flush			
FORD	Kuga III/Escape IV (no tetto in vetro)	5	20>	Smooth	000126800000	000134700000	KIT04G
FORD	Maverick		93>99	Raised			
FORD	Maverick		21>	Smooth	000126900000	000134800000	KIT19G
FORD	Mondeo I		93>00				
FORD	Mondeo I Wagon		93>00	Raised			
FORD	Mondeo II		01>06				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
FORD	Mondeo II Wagon		01>06	Raised			
FORD	Mondeo III Liftback	5	07>14	Smooth	000126800000	000134700000	KIT03G
FORD	Mondeo III Wagon	5	07>10	Raised			
FORD	Mondeo III Wagon	5	10>14	Flush			
FORD	Mondeo III Wagon	5	10>14	Smooth	000126800000	000134700000	KIT03G
FORD	Mondeo III Wagon	5	07>10	Smooth	000126800000	000134700000	KIT03G
FORD	Mondeo IV	4	14>	Smooth	000126800000	000134700000	KIT36G
FORD	Mondeo IV Wagon	5	14>	Flush			
FORD	Mondeo IV Wagon	5	14>	Smooth	000126800000	000134700000	KIT38G
FORD	Mustang Mach-E	5	20>	Smooth			NA
FORD	Puma	5	20>	Smooth			NA
FORD	Puma	5	20>	Flush			
FORD	Ranger T6 (P375)	4	11>	Raised			
FORD	Ranger T6 (P375)	4	11>	Smooth	000126800000	000134700000	KIT19G
FORD	Ranger T6.2 (P703)	4	22>	Smooth	000126800000	000134700000	KIT76G
FORD	S-Max I (No tetto in vetro / No glass sunroof)	5	06>15	Smooth	000126800000	000134700000	FIX203FP
FORD	S-Max I (tetto in vetro / glass sunroof)	5	06>15	Smooth	000126800000	000134700000	FIX203FP
FORD	S-Max II	5	15>	Smooth	000126800000	000134700000	KIT19G
FORD	Taurus VI	4	10>19	Smooth	000126800000	000134700000	KIT27G
FORD	Territory	5	22>	Flush			
FORD	Tourneo Connect	5	13>21	Raised			
FORD	Tourneo Connect	5	21>	Raised			
FORD	Tourneo Courier	5	23>	Raised			
FORD	Tourneo Courier	5	18>23	Raised			
FORD	Tourneo Courier	5	13>18	Raised			
FORD	Transit Courier	5	14>	Raised			
HONDA	Accord IX Sedan	4	13>18	Smooth	000126800000	000134700000	KIT76G
HONDA	Accord VI		98>02				
HONDA	Accord VI Aerodeck		98>02	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HONDA	Accord VI Tourer		98>03	Raised			
HONDA	Accord VII		03>07				
HONDA	Accord VII Tourer		03>07	Raised			
HONDA	Accord VIII		08>				
HONDA	Accord VIII Tourer		08>	Raised			
HONDA	Accord X Sedan	4	18>	Smooth	000126800000	000134700000	KIT04G
HONDA	Civic Aerodeck		96>01				
HONDA	Civic VI Hatchback	5	96>01	Smooth	000126700000	000134600000	KIT17G
HONDA	Civic VIII Hatchback		06>11				
HONDA	Civic VIII Hybrid		06>11				
HONDA	Civic VIII Sedan	4	06>11	Smooth	000126800000	000134700000	KIT19G
HONDA	Civic IX (FB) Sedan	4	12>15	Smooth	000126800000	000134700000	KIT19G
HONDA	Civic IX Hatchback	5	11>15	Smooth	000126800000	000134700000	KIT19G
HONDA	Civic IX Tourer	5	13>15	Flush			
HONDA	Civic X (FC) Sedan	4	16>21	Smooth	000126800000	000134700000	KIT79G
HONDA	Civic X Hatchback		16>21				
HONDA	Civic XI	5	21>	Smooth	000126800000	000134700000	KIT79G
HONDA	CR-V I		96>02	Raised			
HONDA	CR-V II		02>07	Raised			
HONDA	CR-V III	5	07>12	Smooth	000126800000	000134700000	KIT12G
HONDA	CR-V IV (Flush Rails)	5	12>16				NA
HONDA	CR-V IV (No Rails)	5	12>16		000126800000	000134700000	KIT06G
HONDA	CR-V V	5	17>	Flush			
HONDA	CR-V V	5	17>	Smooth	000126800000	000134700000	KIT06G
HONDA	CR-V VI	5	22>	Flush			
HONDA	CR-Z		10>				
HONDA	Edix		04>11	Raised			
HONDA	Elysion		04>15	Raised			
HONDA	FR-V		04>09	Raised			
HONDA	HR-V (GH)	3	99>05				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HONDA	HR-V (GH) (No rails)	3	99>06	Smooth	000126800000	000134700000	KIT09G
HONDA	HR-V / Vezel / XR-V (RU)	5	15>21	Flush			
HONDA	HR-V / Vezel / XR-V (RU)	5	15>21	Smooth	NA	NA	NA
HONDA	HR-V III/ Vezel / XR-V (RU)	5	21>	Raised			
HONDA	HR-V III/ Vezel / XR-V (RU)	5	21>	Smooth	000126800000	000134700000	KIT04G
HONDA	Insight II	5	09>14	Smooth	000126800000	000134700000	KIT19G
HONDA	Insight III	4	19>	Smooth	000126800000	000134700000	KIT80G
HONDA	Jazz / Fit (GD)		01>08				
HONDA	Jazz / Fit (GE)	5	07>14	Smooth	000126700000	000134600000	KIT19G
HONDA	Jazz / Fit (GK)	5	13>19	Smooth	000126700000	000134600000	KIT13G
HONDA	Jazz / Fit (GR)	5	20>	Smooth	000126800000	000134700000	KIT29G
HONDA	Jazz / Fit (GR) Crosstar	5	20>	Raised			
HONDA	Legend III		96>03				
HONDA	Life		99>08	Raised			
HONDA	Logo		96>01				
HONDA	Odissey		03>08	Raised			
HONDA	Odissey		10>	Raised			
HONDA	Passport III	5	19>	Raised			
HONDA	Passport III	5	19>	Smooth	000126900000	000134800000	KIT19G
HONDA	Pilot I		03>08	Raised			
HONDA	Pilot II	5	09>15	Flush			
HONDA	Pilot II	5	09>15	Smooth	000126900000	000134800000	KIT81G
HONDA	Pilot III	5	16>	Smooth	000126900000	000134800000	KIT19G
HONDA	Pilot III	5	23>	Raised			
HONDA	Ridgeline	5	17>	Raised			
HONDA	Shuttle		10>	Raised			
HONDA	Tuourer		14>	Flush			
HONDA	Z		99>02	Raised			
HONDA	ZRV	5	23>	Smooth	000126800000	000134700000	KIT04G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HYUNDAI	Accent I		95>99				
HYUNDAI	Accent IV (RB) Hatchback	5	11>18	Smooth	000126800000	000134700000	FIX209FP
HYUNDAI	Accent IV (RB) Sedan	4	11>18	Smooth	000126700000	000134600000	KIT16G
HYUNDAI	Accent V (HC) Hatchback	5	17>	Smooth	000126700000	000134600000	KIT19G
HYUNDAI	Accent V (HC) Sedan	4	17>	Smooth	000126700000	000134600000	KIT08G
HYUNDAI	Atos	5	97>08	Raised			
HYUNDAI	Atos	5	97>08	Smooth	000126700000	000134600000	KIT35G
HYUNDAI	Atos Prime	5	99>08	Smooth	000126700000	000134600000	KIT21G
HYUNDAI	Avante		96>	Raised			
HYUNDAI	Bayon	5	21>	Flush			
HYUNDAI	Bayon	5	21>	Smooth	000126800000	000134700000	KIT04G
HYUNDAI	Elantra GT (PD)	5	17>20	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Elantra V (UD)	5	11>15	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Elantra VI (AD)	5	16>20	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Elantra	5	20>	Smooth	000126800000	000134700000	KIT91G
HYUNDAI	Entourage II (VQ)		06>14	Raised			
HYUNDAI	Genesis	4	15>	Smooth	000126800000	000134700000	KIT38G
HYUNDAI	Genesis (BH)	4	09>14	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	Genesis (HD)	4	15>16	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Getz		02>11				
HYUNDAI	Getz Cross		06>11	Raised			
HYUNDAI	H-1 II		07>	Raised			
HYUNDAI	HB20		12>	Smooth			
HYUNDAI	i10 (IA)	5	13>17	Smooth	000126700000	000134600000	KIT19G
HYUNDAI	i10 (IA)	5	17>19	Smooth	000126700000	000134600000	KIT19G
HYUNDAI	i10 (AC3)	5	19>	Smooth	000126700000	000134600000	KIT19G
HYUNDAI	i10 (PA)	5	07>13	Smooth	000126700000	000134600000	KIT19G
HYUNDAI	i10	5	23>	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	i20 (BC3)	5	20>	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	i20 (BC3) N	5	20>	Smooth	000126800000	000134700000	KIT19G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HYUNDAI	i20 (GB)	5	14>20	Smooth	000126700000	000134600000	FIX209FP
HYUNDAI	i20 (GB) Active	5	15>20	Raised			
HYUNDAI	i20 (GB) Coupé	3	15>20	Smooth	000126700000	000134600000	FIX209FP
HYUNDAI	i20 (PB)	5	08>14	Smooth	000126700000	000134600000	KIT17G
HYUNDAI	i30 (FD)		07>12				
HYUNDAI	i30 (FD) Wagon		07>10	Raised			
HYUNDAI	i30 (FD) Wagon		10>12				
HYUNDAI	i30 (GD)	5	11>15	Smooth	000126800000	000134700000	KIT04G
HYUNDAI	i30 (GD) Wagon		12>15				
HYUNDAI	i30 (PD) (No tetto in vetro / No glass sunroof)	3	16>	Smooth	000126700000	000134600000	FIX209FP
HYUNDAI	i30 (PD) (No tetto in vetro / No glass sunroof)	5	16>	Smooth	000126700000	000134600000	FIX209FP
HYUNDAI	i30 (PD) Fastback (No tetto in vetro / No glass sunroof)	5	16>	Smooth	000126700000	000134600000	FIX209FP
HYUNDAI	i30 (PD) Wagon	5	16>	Flush			
HYUNDAI	i40 Wagon		11>				
HYUNDAI	Ioniq	5	16>	Smooth			NA
HYUNDAI	Ioniq (AE)	4	16>	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Ioniq 5	5	21>	Smooth	000126800000	000134700000	KIT04G
HYUNDAI	Ioniq 6	4	22>	Smooth	NA	NA	NA
HYUNDAI	ix20	5	10>	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	ix25 / Creta / Cantus		14>18	Raised			
HYUNDAI	ix25 / Creta / Cantus		20>	Flush			
HYUNDAI	ix35 (Flush rail)		10>15	Flush			
HYUNDAI	ix35 (Raised rail)		10>15	Raised			
HYUNDAI	JM		04>09	Raised			
HYUNDAI	Kona	5	17>23	Flush			
HYUNDAI	Kona	5	17>23	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	Kona Electric	5	18>23	Flush			
HYUNDAI	Kona Electric	5	18>23	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	Kona Hybrid	5	19>23	Flush			
HYUNDAI	Kona Hybrid	5	19>23	Smooth	000126800000	000134700000	KIT19G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HYUNDAI	Kona (sx2)	5	23>	Flush			
HYUNDAI	Kona (sx2)	5	23>	Smooth	000126800000	000134700000	KIT93G
HYUNDAI	Kona Electric (sx2)	5	23>	Flush			
HYUNDAI	Kona Hybrid (sx2)	5	23>	Flush			
HYUNDAI	Lantra / Elantra (HD)		06>10				
HYUNDAI	Lantra / Elantra (J2)		95>00				
HYUNDAI	Lantra / Elantra (J2) Station Wagon		95>00	Raised			
HYUNDAI	Lantra / Elantra (XD)		00>06				
HYUNDAI	Lavita		01>10	Raised			
HYUNDAI	Matrix		01>08	Raised			
HYUNDAI	Maxcruz / Santa Fe (DM/NC)	5	12>18	Flush			
HYUNDAI	Maxcruz / Santa Fe (DM/NC)	5	12>18	Smooth	000126800000	000134700000	KIT10G
HYUNDAI	Palisade	5	19>	Flush			
HYUNDAI	Santa Cruz	4	21>	Flush			
HYUNDAI	Santa Fe (CM)	5	06>12	Raised			
HYUNDAI	Santa Fe (SM)	5	00>06	Raised			
HYUNDAI	Santa Fe (TM)	5	19>	Flush			
HYUNDAI	Santa Fe (TM)	5	23>	Raised			
HYUNDAI	Santamo		96>03	Raised			
HYUNDAI	Satellite		98>07	Raised			
HYUNDAI	Sonata VI (YF)	4	09>14	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Sonata VII (LF)	4	15>19	Smooth	000126800000	000134700000	KIT08G
HYUNDAI	Sonata	4	19>	Smooth	000126800000	000134700000	KIT37G
HYUNDAI	Sonica (EF)		98>05				
HYUNDAI	Sonica (Y2)		93>98				
HYUNDAI	Starex		97>07	Raised			
HYUNDAI	Staria	5	21>	Smooth	NA	NA	NA
HYUNDAI	TB		06>11	Raised			
HYUNDAI	Terracan		02>06	Raised			
HYUNDAI	Trajet		99>08	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
HYUNDAI	Tucson		04>09	Raised			
HYUNDAI	Tucson (NX4)	5	20>	Smooth	000126800000	000134700000	KIT19G
HYUNDAI	Tucson (NX4)	5	20>	Flush			
HYUNDAI	Tucson (TL)	5	15>	Flush			
HYUNDAI	Tucson (TL)	5	15>	Smooth	000126800000	000134700000	KIT38G
HYUNDAI	Veloster		11>				
HYUNDAI	Venue	5	20>	Raised			
HYUNDAI	Veracruz		07>12	Raised			
INFINITI	EX (J50)	4	07>13	Raised			
INFINITI	FX (S51)	5	03>13	Raised			
INFINITI	G (V36)	4	07>15				
INFINITI	G Coupe	2	08>15				
INFINITI	M (Y50)	4	06>10				
INFINITI	Q30	5	15>19	Flush			
INFINITI	Q30	5	15>19	Smooth	000126700000	000134600000	FIX206FP
INFINITI	Q50 (V37)	4	13>	Smooth	000126800000	000134700000	KIT69G
INFINITI	Q60	2	17>				
INFINITI	Q60 (CV36)	4	13>15				
INFINITI	Q70 (Y51)	4	13>	Smooth	000126800000	000134700000	KIT68G
INFINITI	Qx30	5	16>19	Flush			
INFINITI	Qx30	5	16>19	Smooth	000126700000	000134600000	FIX206FP
INFINITI	Qx50 (J50)	5	13>	Raised			
INFINITI	QX60	5	13>				
INFINITI	Qx70 (S51)	5	13>	Raised			
INFINITI	Qx80 (Z62)	5	10>	Raised			
ISUZU	AUV		98>17	Raised			
ISUZU	Crosswind (TBR541)		00>	Raised			
ISUZU	D-Max	4	02>12	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
ISUZU	D-Max	4	12>19	Raised			
ISUZU	D-Max	4	12>19	Smooth			NA
ISUZU	D-Max	4	19>	Smooth	000126800000	000134700000	KIT02G
ISUZU	Hi-Lander (TBR541)		00>	Raised			
ISUZU	Panther (TBR541)		00>	Raised			
ISUZU	Rodeo		98>04	Raised			
ISUZU	Trooper		99>05	Raised			
JAGUAR	E-Pace (X540)	5	17>	Smooth	000126800000	000134700000	KIT08G
JAGUAR	F-Pace (X761)	5	16>	Flush			
JAGUAR	F-Pace (X761)	5	16>	Smooth	000126800000	000134700000	KIT47G
JAGUAR	F-Type Cabrio		13>				
JAGUAR	F-Type Coupé		14>				
JAGUAR	I-Pace	5	18>	Smooth	000126800000	000134700000	KIT02G
JAGUAR	S-Type		99>08				
JAGUAR	XE	4	15>	Smooth	000126800000	000134700000	KIT02G
JAGUAR	XF (X250)	4	08>15	Smooth	000126800000	000134700000	KIT02G
JAGUAR	XF (X250) Sportbrake	5	08>15	Flush			
JAGUAR	XF (X260)	4	15>20	Smooth	000126800000	000134700000	KIT49G
JAGUAR	XF	4	21>	Smooth	000126800000	000134700000	KIT49G
JAGUAR	XJ (X351)		09>				
JAGUAR	XK		99>06				
JAGUAR	X-Type		01>09				
JAGUAR	X-Type Wagon		01>09	Raised			
JEEP	Avenger	5	23>	Smooth	000126800000	000134700000	KIT82G
JEEP	Cherokee (KJ)	5	01>04	Raised			
JEEP	Cherokee (KJ)	5	05>07	Raised			
JEEP	Cherokee (KK)	5	08>13	Raised			
JEEP	Cherokee (KL)	5	14>	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
JEEP	Cherokee (KL)	5	14>	Smooth	000126800000	000134700000	KIT10G
JEEP	Cherokee (XJ)	5	96>01				
JEEP	Compass (Mk49)	5	07>17				
JEEP	Compass (MP/552)	5	17>	Smooth	000126800000	000134700000	KIT27G
JEEP	Compass (MP/552)	5	17>	Flush			
JEEP	Grand Cherokee (WJ)	5	99>04	Raised			
JEEP	Grand Cherokee (WK/WH)	5	05>10	Raised			
JEEP	Grand Cherokee (WK2)	5	10>	Smooth	000126800000	000134700000	KIT19G
JEEP	Patriot	5	07>12	Raised			
JEEP	Renegade (BU)	5	14>	Raised			
JEEP	Renegade (BU)	5	14>	Smooth	000126800000	000134700000	KIT02G
JEEP	Wrangler (JK)	2	06>18				NA
JEEP	Wrangler (JK)	4	06>18				NA
JEEP	Wrangler (JL)	2	18>				NA
JEEP	Wrangler (JL)	4	18>				NA
KIA	Carens (RS)		99>06	Raised			
KIA	Carens (UN)		06>13	Raised			
KIA	Carens (RP)	5	13>19	Flush			
KIA	Carens (RP)	5	13>19	Smooth	000126800000	000134700000	KIT10G
KIA	Carnival / Sedona (GQ)	5	98>05	Raised			
KIA	Carnival / Sedona (VQ)	5	06>11	Raised			
KIA	Grand Carnival / Grand Sedona (VQ)	5	06>11	Raised			
KIA	Carnival III/Gran Carnival III /Gran Sedona III/Sedona III (YP)	5	14>	Flush			
KIA	Ceed (CD) (No tetto in vetro / No glass sunroof)	5	18>	Smooth	000126700000	000134600000	FIX209FP
KIA	Ceed (CD) SportsWagon	5	18>	Flush			
KIA	Ceed (CD) SportsWagon	5	18>	Smooth	000126800000	000134700000	KIT49G
KIA	Cee'D (ED)	5	06>12				
KIA	Cee'D (ED) SportsWagon	5	06>12	Raised			
KIA	Cee'D (EU/JD) (No tetto in vetro / No glass sunroof)	5	12>18	Smooth	000126700000	000134600000	FIX209FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
KIA	Cee'D (EU/JD) SportsWagon		12>18	Flush			
KIA	Cerato (LD)		03>08				
KIA	Clarus		95>01	Raised			
KIA	EV3	5	24>	Flush			
KIA	EV5	5	23>	Flush			
KIA	EV9						
KIA	EV6 (no tetto vetro)	5	21>	Smooth	000126800000	000134700000	KIT10G
KIA	Forte II (YD) Sedan	4	14>18	Smooth	000126800000	000134700000	KIT36G
KIA	Forte III (BD) Sedan	4	19>	Smooth	000126800000	000134700000	KIT36G
KIA	Joice		00>02	Raised			
KIA	K5	4	21>	Smooth	000126800000	000134700000	KIT78G
KIA	Magentis (MG)		05>11				
KIA	Niro (DE)	5	16>21	Flush			
KIA	Niro/e Niro/Niro EV (SG2)	5	21>	Flush			
KIA	Opirus		03>10				
KIA	Optima	4	05>11				
KIA	Optima (JF)	4	15>19	Smooth	000126800000	000134700000	KIT36G
KIA	Optima (JF) SportsWagon	5	15>19	Flush			
KIA	Picanto (JA)	5	17>	Smooth	000126700000	000134600000	KIT19G
KIA	Picanto (SA)	5	04>10	Smooth	000126700000	000134600000	KIT21G
KIA	Picanto (TA)	5	11>17	Smooth	000126700000	000134600000	KIT19G
KIA	Pregio		04>06				
KIA	Pride		00>05				
KIA	Pride		97>00	Raised			
KIA	Pro_Cee'D	5	07>13				
KIA	Pro_Cee'D (CD) (No tetto in vetro / No glass sunroof)	5	18>	Smooth	000126700000	000134600000	FIX209FP
KIA	Proo_Cee'D GT	5	13>18				
KIA	Rio (DE) Hatchback	5	05>11	Smooth	000126700000	000134600000	KIT19G
KIA	Rio (UB) Hatchback	5	11>15	Smooth	000126700000	000134600000	KIT35G
KIA	Rio (YB) Hatchback	5	17>	Smooth	000126800000	000134700000	KIT19G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
KIA	Rondo		07>13	Raised			
KIA	Seltos	5	23>	Flush			
KIA	Sorento I (BL)	5	02>09	Raised			
KIA	Sorento II (XM)	5	09>14	Raised			
KIA	Sorento III (UM)	5	14>18	Flush			
KIA	Sorento III (UM)	5	19>20	Flush			
KIA	Sorento III (UM)	5	19>20	Smooth	000126800000	000134700000	KIT08G
KIA	Sorento IV Hybrid / Plug-in (MQ4)	5	20>	Flush			
KIA	Sorento IV Hybrid / Plug-in (MQ4)	5	24>	Flush			
KIA	Soul (AM)		08>14	Raised			
KIA	Soul (PS)	5	13>18	Flush			
KIA	Soul (PS)	5	13>18	Smooth			
KIA	Sportage (JA)		94>02	Raised			
KIA	Sportage (JE_KM)		04>10	Raised			
KIA	Sportage (SL)	5	10>13	Smooth	000126800000	000134700000	KIT10G
KIA	Sportage (SL)	5	10>13	Flush			
KIA	Sportage (SL)	5	14>16	Flush			
KIA	Sportage (QL)	5	16>21	Smooth	000126800000	000134700000	KIT04G
KIA	Sportage (QL)	5	16>21	Flush			
KIA	Sportage (NQ5)	5	21>	Flush			
KIA	Stinger	4	18>	Smooth	000126800000	000134700000	KIT19G
KIA	Stonic	5	17>	Raised			
KIA	Stonic	5	17>	Smooth	000126800000	000134700000	KIT02G
KIA	Telluride	5	19>	Flush			
KIA	Venga		10>14				
KIA	Venga		14>				
KIA	Venga (No tetto in vetro / No glass sunroof)	5	14>	Smooth	000126800000	000134700000	KIT08G
KIA	Venga (No tetto in vetro / No glass sunroof)	5	10>14	Smooth	000126800000	000134700000	KIT35G
KIA	X-Cee'd (CD)	5	19>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
LAND ROVER	Defender (L663)	5	19>				NA
LAND ROVER	Discovery 2 (L318)	5	98>04	Raised			
LAND ROVER	Discovery 3 (L319)	5	04>09	Smooth			
LAND ROVER	Discovery 4 (L319)	5	10>16	Smooth			
LAND ROVER	Discovery 5 (L462)	5	17>	Flush			
LAND ROVER	Discovery Sport (L550)	5	15>19	Raised			
LAND ROVER	Discovery Sport (L550)	5	15>19	Smooth	000126800000	000134700000	KIT40G
LAND ROVER	Discovery Sport 2	5	19>	Smooth	000126800000	000134700000	KIT02G
LAND ROVER	Freelander (L314)	5	96>06	Raised			
LAND ROVER	Freelander 2 (L359)	5	07>15	Raised			
LAND ROVER	Freelander 2 (L359)	5	07>15	Smooth	000126800000	000134700000	KIT37G
LAND ROVER	Rang Rover 4 (L405)	5	12>21	Smooth	000126900000	000134800000	KIT27G
LAND ROVER	Rang Rover 5 (L460)	5	21>	Smooth	000126900000	000134800000	KIT02G
LAND ROVER	Range Rover 1 Sport (L320)	5	05>13	Smooth			NA
LAND ROVER	Range Rover 2 Sport (L494)	5	14>22	Flush			
LAND ROVER	Range Rover 2 Sport (L494)	5	14>22	Smooth	000126900000	000134800000	KIT27G
LAND ROVER	Range Rover 3 Sport (L461)	5	22>	Smooth	000126900000	000134800000	KIT27G
LAND ROVER	Range Rover 3 (L322)	5	02>12				
LAND ROVER	Range Rover Evoque (L538)	5	11>18	Raised			
LAND ROVER	Range Rover Evoque (L538)	5	11>18	Smooth	000126800000	000134700000	KIT27G
LAND ROVER	Range Rover Evoque (L538) Convertible	5	16>				
LAND ROVER	Range Rover Evoque II (L551)	5	18>	Smooth	000126800000	000134700000	KIT27G
LAND ROVER	Range Rover Velar (L560)	5	17>	Flush			
LEXUS	CT	5	11>	Smooth	000126700000	000134600000	KIT04G
LEXUS	ES (XZ10)	4	18>	Smooth	000126800000	000134700000	KIT08G
LEXUS	GS (L10)	4	11>	Smooth	000126800000	000134700000	KIT29G
LEXUS	GS (S160)	4	97>04				
LEXUS	GS (S190)	4	05>11				
LEXUS	GX (J120)	5	02>09	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
LEXUS	IS (XE10)	4	98>05	Smooth	000126700000	000134600000	KIT21G
LEXUS	IS (XE20)	4	05>13	Smooth	000126700000	000134600000	KIT30G
LEXUS	IS (XE30)	4	13>	Smooth	000126700000	000134600000	KIT19G
LEXUS	IS C	2	08>15				
LEXUS	LBX	5	23>	Smooth	000126800000	000134700000	KIT29G
LEXUS	LS (XF30)	4	03>05				
LEXUS	LS (XF40)	4	06>09				
LEXUS	NX (AZ10)	5	14>	Flush			
LEXUS	NX (AZ10)	5	14>	Smooth	000126800000	000134700000	KIT19G
LEXUS	RC (XC10)	2	14>				
LEXUS	RX (AL10)	5	09>11	Raised			
LEXUS	RX (AL10)	5	12>15				
LEXUS	RX (AL20)	5	15>	Flush			
LEXUS	RX (AL20)	5	15>	Smooth	000126800000	000134700000	KIT08G
LEXUS	UX (ZA10)	5	18>	Flush			
LEXUS	UX (ZA10)	5	18>	Smooth	000126800000	000134700000	KIT49G
MAZDA	5	5	05>08	Raised			
MAZDA	5	5	08>13	Raised			
MAZDA	5	5	13>15	Smooth			
MAZDA	121	4	91>02	Smooth	000126700000	000134600000	KIT13G
MAZDA	323		89>03				
MAZDA	626		88>02				
MAZDA	2 (DE)	3	07>14	Smooth			NA
MAZDA	2 (DE)	5	07>14	Smooth	000126700000	000134600000	KIT06G
MAZDA	2 (DJ)	5	14>	Smooth	000126700000	000134600000	KIT04G
MAZDA	3 / 3 Sport / Axela (BP)	5	19>	Smooth	000126800000	000134700000	KIT27G
MAZDA	3 / Axela (BM)	5	13>18	Smooth	000126800000	000134700000	KIT38G
MAZDA	3 / Axela(BL)	5	09>13	Smooth	000126700000	000134600000	FIX209FP
MAZDA	3 IV (BP) Sedan	4	19>	Smooth	000126800000	000134700000	KIT27G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MAZDA	6 / Atenza (GG)	5	02>08				
MAZDA	6 / Atenza (GG) Wagon	5	02>08	Raised			
MAZDA	6 / Atenza (GH)	5	08>13				
MAZDA	6 / Atenza (GH) Station Wagon	5	08>13	Raised			
MAZDA	6 / Atenza (GJ)	5	12>17	Smooth	000126800000	000134700000	KIT27G
MAZDA	6 / Atenza (GJ) Station Wagon	5	12>17	Raised			
MAZDA	6 / Atenza (GJ) Station Wagon	5	12>17	Smooth	000126800000	000134700000	KIT49G
MAZDA	6 III (GL) Sedan	5	17>	Smooth	000126800000	000134700000	KIT49G
MAZDA	626 Break		88>02	Raised			
MAZDA	BT-50	4	11>	Raised			
MAZDA	BT-50	4	11>	Smooth	000126800000	000134700000	KIT19G
MAZDA	Capella		98>02	Raised			
MAZDA	Cx-3	5	15>	Smooth	000126700000	000134600000	KIT08G
MAZDA	Cx-30	5	19>	Smooth	000126800000	000134700000	KIT02G
MAZDA	Cx-5 (KE)	5	12>14	Smooth	000126800000	000134700000	KIT10G
MAZDA	Cx-5 (KE)	5	14>17	Smooth	000126700000	000134600000	FIX209FP
MAZDA	Cx-5 (KF)	5	17>	Smooth	000126800000	000134700000	KIT08G
MAZDA	Cx-60	5	22>	Smooth	000126900000	000134800000	KIT02G
MAZDA	Cx-7	5	06>12	Smooth	000126700000	000134600000	FIX209FP
MAZDA	Cx-80	5	24>	Flush			
MAZDA	Cx-9	5	06>15	Smooth	000126800000	000134700000	KIT08G
MAZDA	Cx-9 II (TC)	5	16>	Smooth	000126800000	000134700000	KIT02G
MAZDA	Demio		96>02	Raised			
MAZDA	MPV		97>98	Raised			
MAZDA	MPV		99>06				
MAZDA	MX-30	5	20>	Smooth	000126800000	000134700000	KIT38G
MAZDA	MX-5 (NC)		06>14				
MAZDA	MX-5 (ND)		15>				
MAZDA	MX-5 Cult	2	13>	Smooth			NA
MAZDA	Navajo		00>11				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MAZDA	Premacy		05>08	Raised			
MAZDA	Premacy		08>13	Raised			
MAZDA	Proceed Levante (FT/GT)	3	98>05				
MAZDA	Proceed Levante (FT/GT)	5	98>05				
MAZDA	Tribute I		01>07	Raised			
MAZDA	Tribute II		07>12	Raised			
MAZDA	Xedos 6		92>99				
MAZDA	Xedos 9		93>03				
MERCEDES	A (W168)	5	97>04	Smooth	000126700000	000134600000	KIT13G
MERCEDES	A (W169)	5	04>12	Smooth	000126700000	000134600000	FIX201FP
MERCEDES	A (W176)	5	13>18	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	A (W176) 45 Amg		13>18				
MERCEDES	A (W177)	5	18>	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	A Sedan (V177/Z177)	5	18>	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	AMG - GTs (C190)		14>				
MERCEDES	B (W245)	5	05>11	Smooth	000126700000	000134600000	FIX203FP
MERCEDES	B (W246)	5	12>18	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	B (W247)	5	18>	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	C (C205) Coupé	3	15>	Smooth	000126700000	000134600000	FIX204FP
MERCEDES	C (W202)	4	93>00	Smooth	000126800000	000134700000	KIT21G
MERCEDES	C (W204)	4	07>13	Smooth	000126700000	000134600000	FIX204FP
MERCEDES	C (W205)	4	14>21	Smooth	000126700000	000134600000	FIX204FP
MERCEDES	C (W206) / C Class	5	21>	Smooth	000126700000	000134600000	FIX203FP
MERCEDES	C Station Wagon (S202)		93>00	Raised			
MERCEDES	C Station Wagon (S203)		00>07	Raised			
MERCEDES	C Station Wagon (S204)		07>14	Raised			
MERCEDES	C Station Wagon (S205)		14>21	Flush			
MERCEDES	C Station Wagon (S206)	5	21>	Flush			
MERCEDES	Citan (W415)	5	12>		000126700000	000134600000	FIX208FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MERCEDES	CL (C216)		06>10				
MERCEDES	CL (C216)		10>13				
MERCEDES	CLA (C117)	4	13>19	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	CLA (C118)	4	19>	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	CLA Shooting Brake (X117)	5	15>19	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	CLA Shooting Brake (X118)	5	19>	Smooth	000126700000	000134600000	FIX206FP
MERCEDES	CLS (C218)	4	10>	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	CLS (C219)	4	04>10	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	CLS (X218) Shooting Brake	5	12>	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	E (W210)	4	95>02	Smooth	000126800000	000134700000	KIT21G
MERCEDES	E (W211)	4	02>09	Smooth	000126700000	000134600000	FIX201FP
MERCEDES	E (W212)	4	09>13	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	E (W212)	4	13>16	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	E (W213)	4	16>	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	E Break (S210)		95>02	Raised			
MERCEDES	E Coupé (C207)	2	09>16				
MERCEDES	E Coupé (C238)	2	16>	Smooth	000126700000	000134600000	FIX203FP
MERCEDES	E Station Wagon (S211)	5	03>08	Raised			
MERCEDES	E Station Wagon (S212)	5	09>16	Raised			
MERCEDES	E Station Wagon (S213)	5	16>	Flush			
MERCEDES	EQA (H243)	5	21>	Flush			
MERCEDES	EQB (X243)	5	21>	Raised			
MERCEDES	EQE (V295)	4	22>	Smooth	000126800000	000134700000	FIX203FP
MERCEDES	EQS (V297)	5	21>	Smooth	000126800000	000134700000	FIX203FP
MERCEDES	EQS SUV (X297)	5	22>	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	G (W464)	5	18>	Smooth			
MERCEDES	G (W463)	5	18>	Smooth	000126800000	000134700000	FIX206FP
MERCEDES	GL (X164)		06>12	Raised			
MERCEDES	GL (X166)		12>	Raised			
MERCEDES	GLA (X156)		14>20	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MERCEDES	GLA (H247)	5	20>	Flush			
MERCEDES	GLB (X247)	5	19>	Raised			
MERCEDES	GLC (X253)	5	15>20	Flush			
MERCEDES	GLC (X253)	5	20>	Flush			
MERCEDES	GLC (X253)	5	15>20	Smooth	000126800000	000134700000	KIT02G
MERCEDES	GLC Coupé (C253)	5	15>23	Smooth	000126700000	000134600000	FIX203FP
MERCEDES	GLE (W166)	5	15>18	Raised			
MERCEDES	GLE Coupé (C292)	5	15>18	Smooth	000126800000	000134700000	FIX206FP
MERCEDES	GLE (V167)	5	18>	Raised			
MERCEDES	GLE Coupé (C167)	5	18>	Smooth	000126800000	000134700000	FIX206FP
MERCEDES	GLK (X204)	5	08>15	Raised			
MERCEDES	GLS (X167)	5	19>	Raised			
MERCEDES	M (W163)	5	97>05	Raised			
MERCEDES	M (W164)	5	05>11	Raised			
MERCEDES	M (W166)	5	11>15	Raised			
MERCEDES	R (W251)	5	05>13	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	S (W220)		99>05				
MERCEDES	S (W221)		05>13				
MERCEDES	S (W222)	4	14>20	Smooth	000126700000	000134600000	FIX204FP
MERCEDES	S (W223)	4	20>	Smooth	000126800000	000134700000	FIX204FP
MERCEDES	SL (R231)		11>				
MERCEDES	SLC (R172)		16>				
MERCEDES	SLK (R172)		11>16				
MERCEDES	SLS Electric	2	13>	Smooth			NA
MERCEDES	V (W447)		14>	Raised			
MERCEDES	Vaneo (W414)		02>05	Raised			
MERCEDES	Viano (W639)		03>13	Raised			
MERCEDES	Vito (W638)		97>03	Raised			
MERCEDES	X (470)	4	18>	Raised			
MERCEDES	X (470)	4	18>	Smooth	000126800000	000134700000	KIT08G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MG	4/4 EV/Mulan (EH32)	5	22>	Smooth	000126800000	000134700000	KIT76G
MG	MG3 III	5	24>	Smooth	000126800000	000134700000	KIT02G
MG	MG5 (SW)	5	21>	Raised			
MG	GS 1.5T						
MG	HS I	5	18>24	Flush			
MG	HS II	5	24>	Flush			
MG	ONE	5	21>	Flush			
MG	Marvel R	5	21>	Flush			
MG	XR5						
MG	ZS I	5	17>	Raised			
MG	ZS II	5	24>	Flush			
MG	ZT-T Station Wagon		01>05	Raised			
MINI	Cabrio		09>				
MINI	Clubman (F54)	5	15>	Smooth			NA
MINI	Clubman (R55)		07>14	Raised			
MINI	Countryman (F60)	5	17>	Raised			
MINI	Countryman (R60)	5	10>16	Flush			
MINI	Countryman (U25)	5	23>	Flush			
MINI	Coupé		10>				
MINI	One / Cooper	3	01>13	Smooth	000126700000	000134600000	KIT17G
MINI	One / Cooper	3	14>18	Smooth	NA	NA	NA
MINI	One / Cooper	3	18>	Smooth	NA	NA	NA
MINI	One / Cooper	5	14>18	Smooth	000126700000	000134600000	KIT10G
MINI	One / Cooper	5	18>	Smooth	NA	NA	NA
MINI	Paceman (R61)	3	13>16				
MINI	Roadster		12>				
MITSUBISHI	ASX	5	10>22	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
mitsubishi	ASX	5	10>22	Smooth	000126700000	000134600000	FIX203FP
mitsubishi	ASX	5	23>	Flush			
mitsubishi	ASX	5	23>	Smooth	000126800000	000134700000	KIT82G
mitsubishi	Carisma		95>04				
mitsubishi	Challenger		99>	Raised			
mitsubishi	Chariot Grandis		97>03	Raised			
mitsubishi	Colt V (CJO)		95>02				
mitsubishi	Colt VI (Z30)		02>08				
mitsubishi	Colt VI (Z30)		09>12				
mitsubishi	Colt VII	5	23>	Smooth	000126700000	000134600000	KIT48G
mitsubishi	Dingo		99>01	Raised			
mitsubishi	Eclipse Cross		18>	Flush			
mitsubishi	Eclipse III		00>05				
mitsubishi	Galant		96>03				
mitsubishi	Galant Break		96>03				
mitsubishi	Galant Station Wagon		96>03	Raised			
mitsubishi	Grandis		03>11	Raised			
mitsubishi	I-Miev	5	10>	Smooth	000126700000	000134600000	KIT10G
mitsubishi	L200 / Triton IV	4	06>15	Smooth	000126800000	000134700000	KIT19G
mitsubishi	L200 / Triton V	4	15>	Smooth	000126800000	000134700000	KIT12G
mitsubishi	Lancer Evolution X		08>				
mitsubishi	Lancer IX		07>				
mitsubishi	Lancer VII	4	95>00	Smooth	000126700000	000134600000	FIX203FP
mitsubishi	Lancer VIII		00>07				
mitsubishi	Legnum		97>05	Raised			
mitsubishi	Libero		99>05	Raised			
mitsubishi	Spacestar / Mirage (A00) Hatchback	5	12>	Smooth	000126800000	000134700000	KIT76G
mitsubishi	Spacestar / Mirage (A00)	5	12>16	Smooth	000126700000	000134600000	KIT01G
mitsubishi	Spacestar / Mirage (A00)	5	17>	Smooth	000126700000	000134600000	KIT04G
mitsubishi	Attrage / Mirage G4 (A10) Sedan	4	13>	Smooth	000126800000	000134700000	KIT68G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
MITSUBISHI	Montero / Nativ / Pajero / Shogun (V60)		99>06	Raised			
MITSUBISHI	Montero / Nativ / Pajero / Shogun (V80)		06>	Raised			
MITSUBISHI	Nimbus		98>03	Raised			
MITSUBISHI	Outlander (GF/GG/ZJ/ZK)		13>	Flush			
MITSUBISHI	Outlander (US)(GM,GN,ZM)	5	21>	Flush			
MITSUBISHI	Outlander (CU/ZE/ZF)		01>08	Raised			
MITSUBISHI	Outlander (CW/ZG/ZH)		06>12	Raised			
MITSUBISHI	Outlander PHEV		14>	Flush			
MITSUBISHI	Outlander Sport / RVR	5	10>	Flush			
MITSUBISHI	Outlander Sport / RVR	5	10>	Smooth	000126700000	000134600000	FIX203FP
MITSUBISHI	Pinin		98>07	Raised			
MITSUBISHI	Space Runner		91>02	Raised			
MITSUBISHI	Space Wagon		03>11	Raised			
MITSUBISHI	Space Wagon		84>98	Raised			
MITSUBISHI	Space Wagon		99>03	Raised			
MITSUBISHI	Spacestar		98>05	Raised			
MITSUBISHI	Xpander Cross (3-Cropped)		23>	Raised			
NISSAN	200 Nx		91>				
NISSAN	370 Z		09>				
NISSAN	Almera (N15)	5	95>00	Raised			
NISSAN	Almera (N15)	5	95>00	Smooth	000126700000	000134600000	KIT22G
NISSAN	Almera (N16)	5	00>03	Raised			
NISSAN	Almera (N16)	5	00>03	Smooth	000126700000	000134600000	KIT22G
NISSAN	Almera Tino	5	00>06	Raised			
NISSAN	Almera Tino	5	00>06	Smooth	000126700000	000134600000	KIT22G
NISSAN	Altima (L34)	4	19>	Smooth	000126800000	000134700000	KIT76G
NISSAN	Armada (Y62)	5	17>	Raised			
NISSAN	Ariya	5	21>	Smooth			NA
NISSAN	Cube	5	08>13	Smooth	000126900000	000134800000	KIT21G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
NISSAN	Grand Livina		13>	Raised			
NISSAN	GTR		09>				
NISSAN	Juke (F16)	5	19>	Smooth	000126700000	000134600000	KIT49G
NISSAN	Juke (F15)	5	10>19	Smooth	000126700000	000134600000	KIT02G
NISSAN	Kicks (P15)	5	16>	Smooth	000126700000	000134600000	KIT04G
NISSAN	Kubistar		03>09	Smooth	000126700000	000134600000	FIX208FP
NISSAN	Lafesta		04>12	Raised			
NISSAN	Leaf (ZE0)	5	10>16	Smooth	000126800000	000134700000	KIT10G
NISSAN	Leaf (ZE0)	5	16>18	Smooth	000126800000	000134700000	KIT04G
NISSAN	Leaf (ZE1)	5	18>	Smooth	000126800000	000134700000	KIT10G
NISSAN	Livina X-Gear		13>	Raised			
NISSAN	Maxima	4	16>23	Smooth	000126800000	000134700000	KIT02G
NISSAN	Maxima VI		03>08				
NISSAN	Micra / March (K11)	3	92>03	Smooth	000126700000	000134600000	KIT14G
NISSAN	Micra / March (K11)	5	92>03	Smooth	000126700000	000134600000	KIT13G
NISSAN	Micra / March (K12)	5	02>10	Smooth	000126700000	000134600000	KIT03G
NISSAN	Micra / March (K13)	5	10>17	Smooth	000126700000	000134600000	KIT02G
NISSAN	Micra / March (K14)	5	17>	Smooth	000126700000	000134600000	KIT19G
NISSAN	Murano (Z50)	5	02>07	Raised			
NISSAN	Murano (Z51)	5	08>14	Raised			
NISSAN	Navara / Frontier (D41)	4	22>	Smooth	000126800000	000134700000	KIT37G
NISSAN	Navara / Frontier (D40)		04>10	Raised			
NISSAN	Navara / NP300 / Frontier (D23)	4	14>21	Raised			
NISSAN	Navara / NP300 / Frontier (D23)	4	14>21	Smooth	000126800000	000134700000	KIT08G
NISSAN	New Micra (K13)	5	14>	Smooth	000126700000	000134600000	KIT02G
NISSAN	Note / Versa	5	04>12	Smooth	000126700000	000134600000	KIT19G
NISSAN	Note / Versa	5	13>	Smooth	000126800000	000134700000	KIT19G
NISSAN	Nv 200		09>	Smooth	000126800000	000134700000	FIX208FP
NISSAN	Pathfinder (R51)	5	05>12	Flush			
NISSAN	Pathfinder (R52)	5	13>21	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
NISSAN	Pathfinder	5	21>	Raised			
NISSAN	Patrol		87>91	Raised			
NISSAN	Patrol (Y61)		98>05	Raised			
NISSAN	Patrol (Y62)		10>	Raised			
NISSAN	Pixo	5	09>13	Smooth			NA
NISSAN	Presage		98>09	Raised			
NISSAN	Primastar Combi		01>14				
NISSAN	Primera (W12)		91>07	Raised			
NISSAN	Primera Break		90>02	Raised			
NISSAN	Primera Wagon		02>	Raised			
NISSAN	Pulsar	5	14>	Smooth	000126800000	000134700000	KIT10G
NISSAN	Qashqai / Dualis (J10)	5	06>14	Raised			
NISSAN	Qashqai / Dualis (J10)	5	06>14	Smooth	000126800000	000134700000	KIT31G
NISSAN	Qashqai / Dualis (J11)	5	14>17	Raised			
NISSAN	Qashqai / Dualis (J11)	5	17>21	Raised			
NISSAN	Qashqai / Dualis (J11)	5	14>17	Smooth	000126800000	000134700000	KIT48G
NISSAN	Qashqai / Dualis (J11)	5	17>21	Smooth	000126800000	000134700000	KIT48G
NISSAN	Qashqai / Dualis (J12)	5	21>	Flush			
NISSAN	Qashqai / Dualis (J12)	5	21>	Smooth	000126800000	000134700000	KIT36G
NISSAN	Qashqai+2 / Dualis+2 (J10E)		08>13	Raised			
NISSAN	Quest		12>16	Raised			
NISSAN	Rasheen		99>00	Raised			
NISSAN	Rogue		13>17	Raised			
NISSAN	Sentra (B17)	4	13>				
NISSAN	Sentra (B18)	4	19>	Smooth	000126800000	000134700000	KIT10G
NISSAN	Serena		91>02				
NISSAN	Stagea		97>01	Raised			
NISSAN	Terrano 2	5	95>05	Raised			
NISSAN	Terrano 2	5	95>05	Smooth	000126700000	000134600000	KIT22G
NISSAN	Titan (A61)	4	16>24	Smooth	000126900000	000134800000	KIT37G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
NISSAN	Xterra		04>15	Raised			
NISSAN	X-Trail		01>13				
NISSAN	X-Trail (T32) / Rouge S	5	13>22	Raised			
NISSAN	X-Trail (T32) / Rouge S	5	13>22	Smooth	000126700000	000134600000	FIX202FP
NISSAN	X-Trail (T33) / Rouge	5	22>	Flush	000126800000	000134700000	KIT52G
NISSAN	X-Trail (T33) / Rouge	5	22>	Smooth	000126800000	000134700000	KIT52G
OPEL	Adam	3	13>	Smooth	000126700000	000134600000	KIT53G
OPEL	Adam Rocks		15>				
OPEL	Adam S		15>				
OPEL	Agila (B)	5	07>15	Smooth	000126700000	000134600000	KIT17G
OPEL	Ampera	4	12>	Smooth	000126700000	000134600000	KIT10G
OPEL	Antara		06>18	Raised			
OPEL	Astra (F)		91>97				
OPEL	Astra (G)	4	98>04	Smooth	000126700000	000134600000	KIT61G
OPEL	Astra (G) Sportourer		98>04	Raised			
OPEL	Astra (H)	5	04>11	Smooth	000126700000	000134600000	FIX203FP
OPEL	Astra (H) Sportourer	5	04>11	Flush			
OPEL	Astra (H) Sportourer	5	04>11	Smooth	000126700000	000134600000	FIX203FP
OPEL	Astra (J)	5	10>16	Flush			
OPEL	Astra (J)	5	10>16	Smooth	000126700000	000134600000	KIT53G
OPEL	Astra (J) GTC		10>16				
OPEL	Astra (J) GTC OPC		10>16				
OPEL	Astra (J) Sportourer		10>16	Flush			
OPEL	Astra (K)	5	16>21	Smooth	000126800000	000134700000	KIT26G
OPEL	Astra (K) Notchback		16>21				
OPEL	Astra (K) Sportourer	5	16>21				NA
OPEL	Astra (L)	5	22>	Flush			
OPEL	Astra (L)	5	21>	Smooth	000126800000	000134700000	KIT48G
OPEL	Cascada		13>				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
OPEL	Combo (C)		01>11	Smooth			NA
OPEL	Combo (D)		12>18	Raised			
OPEL	Combo (D)		12>14	Smooth			NA
OPEL	Combo (D)		14>18	Smooth	000126800000	000134700000	FIX208FP
OPEL	Combo (D) Tour		12>14	Raised			
OPEL	Combo (D) Tour		12>14	Smooth			NA
OPEL	Combo (D) Van L1		12>14	Smooth			NA
OPEL	Combo (D) Van L2		12>14	Smooth			NA
OPEL	Combo (E)	5	18>	Raised			
OPEL	Combo (E)	5	18>	Smooth	000126800000	000134700000	FIX207FP
OPEL	Corsa / Vita (B)		93>00	Smooth	000126700000	000134600000	KIT61G
OPEL	Corsa / Vita (C)		00>06	Smooth	000126700000	000134600000	KIT61G
OPEL	Corsa / Vita (C) Station Wagon		00>06	Raised			
OPEL	Corsa / Vita (D)	3	06>10	Smooth	000126700000	000134600000	KIT53G
OPEL	Corsa / Vita (D)	3	11>14	Smooth	000126700000	000134600000	KIT53G
OPEL	Corsa / Vita (D)	5	06>10	Smooth	000126700000	000134600000	KIT53G
OPEL	Corsa / Vita (D)	5	11>14	Smooth	000126700000	000134600000	KIT53G
OPEL	Corsa / Vita / Corsavan (E)	5	15>19	Smooth	000126700000	000134600000	KIT53G
OPEL	Corsa (F)	5	19>23	Smooth	000126700000	000134600000	KIT82G
OPEL	Corsa	5	24>	Smooth	000126700000	000134600000	KIT92G
OPEL	Crossland	5	20>	Flush			
OPEL	Crossland	5	20>	Smooth	000126800000	000134700000	KIT26G
OPEL	Crossland X	5	17>20	Flush			
OPEL	Crossland X	5	17>20	Smooth	000126800000	000134700000	KIT26G
OPEL	Grandland X	5	17>	Flush			
OPEL	Grandland X	5	17>	Smooth	000126800000	000134700000	KIT02G
OPEL	GT		07>10				
OPEL	Insignia Sportourer		09>17	Flush			
OPEL	Insignia Sportourer		17>	Flush			
OPEL	Insignia	4	09>17	Smooth	000126800000	000134700000	KIT02G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
OPEL	Insignia Grand Sport	4	17>	Smooth	000126800000	000134700000	KIT36G
OPEL	Karl	5	15>	Smooth	000126700000	000134600000	KIT17G
OPEL	Karl Rocks		17>	Raised			
OPEL	Meriva (A)	5	03>09	Smooth	000126700000	000134600000	KIT53G
OPEL	Meriva (B) (No tetto in vetro / No glass sunroof)	5	10>17	Smooth	000126700000	000134600000	KIT53G
OPEL	Mokka A	5	12>19	Flush			
OPEL	Mokka B	5	20>	Flush			
OPEL	Mokka X	5	16>	Flush			
OPEL	Sintra		96>99	Raised			
OPEL	Vectra (B)		95>02				
OPEL	Vectra (B) Station Wagon		95>02	Raised			
OPEL	Vectra (C)		02>08				
OPEL	Vectra (C) Station Wagon		02>08	Flush			
OPEL	Vivaro (A) Combi / Tourer		01>14				
OPEL	Zafira (A)		98>04	Raised			
OPEL	Zafira (B)	5	05>08	Flush			
OPEL	Zafira (B)	5	08>12	Flush			
OPEL	Zafira (B)	5	05>08	Smooth	000126700000	000134600000	FIX201FP
OPEL	Zafira (B)	5	08>12	Smooth	000126700000	000134600000	FIX201FP
OPEL	Zafira (C) Tourer	5	11>19	Flush			
OPEL	Zafira (C) Tourer	5	11>19	Smooth	000126700000	000134600000	KIT53G
PEUGEOT	106	3	92>04	Smooth	000126700000	000134600000	KIT14G
PEUGEOT	106	5	92>04	Smooth	000126700000	000134600000	KIT13G
PEUGEOT	107	5	05>14	Smooth	000126700000	000134600000	KIT17G
PEUGEOT	108	5	14>	Smooth	000126700000	000134600000	KIT17G
PEUGEOT	206	3	98>09	Smooth			
PEUGEOT	206	5	98>09	Smooth			
PEUGEOT	206 Plus	3	09>12	Smooth			
PEUGEOT	206 Plus	5	09>12	Smooth			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
PEUGEOT	206 Station Wagon		98>02	Raised			
PEUGEOT	206 Station Wagon		02>	Raised			
PEUGEOT	207	5	06>15	Smooth			NA
PEUGEOT	207 Plus		07>14				
PEUGEOT	207 Station Wagon		07>09	Raised			
PEUGEOT	207 Station Wagon		10>14	Raised			
PEUGEOT	208	3	12>15	Smooth			NA
PEUGEOT	208	5	12>15	Smooth	000126700000	000134600000	KIT02G
PEUGEOT	208	5	15>19	Smooth	000126700000	000134600000	KIT03G
PEUGEOT	208 II	5	19>	Smooth	000126700000	000134600000	KIT41G
PEUGEOT	301	4	12>	Smooth			NA
PEUGEOT	306		93>02				
PEUGEOT	306 Break		93>02	Raised			
PEUGEOT	307	3	01>09	Smooth	000126700000	000134600000	FIX203FP
PEUGEOT	307	5	01>09	Smooth	000126700000	000134600000	FIX202FP
PEUGEOT	307 Station Wagon		02>08	Raised			
PEUGEOT	308	5	07>14	Smooth	000126700000	000134600000	FIX205FP
PEUGEOT	308 (No tetto in vetro / No glass sunroof)	5	13>21	Smooth	000126800000	000134700000	KIT41G
PEUGEOT	308 (P5)/308 (MK3)	5	21>	Smooth	000126800000	000134700000	KIT48G
PEUGEOT	308 CC		08>				
PEUGEOT	308 Station Wagon		08>13	Raised			
PEUGEOT	308 Station Wagon	5	14>21	Flush			
PEUGEOT	308 Station Wagon	5	14>21	Smooth	000126800000	000134700000	KIT03G
PEUGEOT	308 Station Wagon (P52) / 308 Station Wagon (MK3)	5	21>	Flush			
PEUGEOT	308 Station Wagon (P52) / 308 Station Wagon (MK3)	5	21>	Smooth	000126800000	000134700000	KIT48G
PEUGEOT	405		87>98				
PEUGEOT	405 / Sedan	4	95>	Smooth	000126700000	000134600000	KIT73G
PEUGEOT	406	4	95>05	Smooth	000126700000	000134600000	KIT34G
PEUGEOT	406 Station Wagon		97>05	Raised			
PEUGEOT	407	4	04>12	Smooth	000126700000	000134600000	FIX205FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
PEUGEOT	407 Coupé		06>12				
PEUGEOT	407 Station Wagon		04>12	Raised			
PEUGEOT	408 Station Wagon		08>				
PEUGEOT	408/408 X (P54)	5	22>		000126800000	000134700000	KIT48G
PEUGEOT	508 I		10>18				
PEUGEOT	508 RXH		12>14				
PEUGEOT	508 II	4	18>	Smooth			NA
PEUGEOT	508 Station Wagon (No tetto in vetro / No glass sunroof)	5	10>18	Flush			
PEUGEOT	508 Station Wagon	5	10>18	Smooth	000126800000	000134700000	KIT02G
PEUGEOT	508 Station Wagon	5	18>	Flush			
PEUGEOT	508 Station Wagon	5	18>	Smooth			NA
PEUGEOT	607	4	00>05	Smooth	000126700000	000134600000	FIX203FP
PEUGEOT	607	4	05>10	Smooth	NA	NA	NA
PEUGEOT	806		94>02				
PEUGEOT	807		02>07				
PEUGEOT	807		08>14				
PEUGEOT	1007		05>10	Raised			
PEUGEOT	2008	5	13>20	Raised			
PEUGEOT	2008	5	20>	Flush			
PEUGEOT	2008	5	20>	Smooth	000126700000	000134600000	KIT49G
PEUGEOT	2008	5	13>20	Smooth			NA
PEUGEOT	3008	5	09>16	Smooth	000126800000	000134700000	FIX205FP
PEUGEOT	3008	5	16>20	Flush			
PEUGEOT	3008	5	16>20	Smooth	000126800000	000134700000	KIT82G
PEUGEOT	3008	5	21>	Flush			
PEUGEOT	3008	5	21>	Smooth	000126800000	000134700000	KIT82G
PEUGEOT	4007		07>12	Raised			
PEUGEOT	4008	5	10>13	Flush			
PEUGEOT	4008	5	10>13	Smooth	000126700000	000134600000	FIX203FP
PEUGEOT	4008	5	13>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
PEUGEOT	4008	5	13>	Smooth	000126700000	000134600000	FIX203FP
PEUGEOT	5008 (No Rails)	5	09>16	Smooth	000126800000	000134700000	FIX205FP
PEUGEOT	5008	5	17>20	Flush			
PEUGEOT	5008	5	17>20	Smooth	000126800000	000134700000	KIT82G
PEUGEOT	5008	5	21>	Flush			
PEUGEOT	5008	5	21>	Smooth	000126800000	000134700000	KIT82G
PEUGEOT	Bipper		08>16	Raised			
PEUGEOT	Bipper		08>	Smooth	000126800000	000134700000	FIX208FP
PEUGEOT	Bipper Tepee		09>	Raised			
PEUGEOT	Expert		07>16	Smooth	000126800000	000134700000	FIX208FP
PEUGEOT	Expert		94>06	Smooth	000126800000	000134700000	FIX208FP
PEUGEOT	ION	5	11>	Smooth	000126700000	000134600000	KIT10G
PEUGEOT	Pars / Persia / Safir	4	01>	Smooth	000126700000	000134600000	KIT73G
PEUGEOT	Partner Air		96>13	Raised			
PEUGEOT	Partner II		08>18	Smooth	000126800000	000134700000	FIX207FP
PEUGEOT	Partner III		18>	Smooth	000126800000	000134700000	FIX207FP
PEUGEOT	Partner Tepee	5	08>18	Raised			
PEUGEOT	Partner Tepee	5	08>18	Smooth	000126800000	000134700000	FIX208FP
PEUGEOT	Ranch	5	96>13	Raised			
PEUGEOT	Ranch	5	96>13	Smooth	000126700000	000134600000	KIT24G
PEUGEOT	RCZ	2	13>	Smooth			NA
PEUGEOT	RCZ		10>13				
PEUGEOT	Rifter	5	18>	Raised			
PEUGEOT	Rifter	5	18>	Smooth	000126800000	000134700000	FIX207FP
PORSCHE	Cayenne (92A)	5	11>17	Raised			
PORSCHE	Cayenne (92A)	5	11>17	Smooth	000126800000	000134700000	KIT08G
PORSCHE	Cayenne (9PA)		03>10	Raised			
PORSCHE	Cayenne (PO536)	5	17>	Flush			
PORSCHE	Cayenne (PO536)	5	17>	Smooth	000126800000	000134700000	KIT02G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
PORSCHE	Macan (95B)	5	13>	Flush			
PORSCHE	Macan (95B)	5	13>	Smooth	000126800000	000134700000	KIT08G
PORSCHE	Panamera (971) Sport Turismo	5	17>	Smooth			NA
PORSCHE	Taycan	5	19>	Smooth	000126700000	000134600000	FIX203FP
PORSCHE	Taycan Sport Turismo	5	19>	Raised			
RENAULT	Alaskan	4	16>	Raised			
RENAULT	Alaskan	4	16>	Smooth	000126800000	000134700000	KIT08G
RENAULT	Arkana	5	20>	Smooth	000126800000	000134700000	KIT48G
RENAULT	Austral	5	22>	Flush			
RENAULT	Captur	5	13>17	Smooth	000126800000	000134700000	KIT39G
RENAULT	Captur	5	17>19	Smooth	000126800000	000134700000	KIT43G
RENAULT	Captur II	5	19>	Smooth	000126800000	000134700000	KIT82G
RENAULT	Captur II	5	19>	Flush			
RENAULT	Clio Collection	3	12>14	Smooth			NA
RENAULT	Clio Collection	5	12>14	Smooth	000126800000	000134700000	KIT60G
RENAULT	Clio II	3	98>05	Smooth	000126700000	000134600000	KIT20G
RENAULT	Clio II	5	98>05	Smooth	000126700000	000134600000	KIT22G
RENAULT	Clio III	3	05>12	Smooth			NA
RENAULT	Clio III	5	05>12	Smooth	000126700000	000134600000	KIT60G
RENAULT	Clio III Sporter		07>12	Raised			
RENAULT	Clio IV	5	12>19	Smooth	000126700000	000134600000	KIT39G
RENAULT	Clio IV Sporter / Grand Tourer	5	13>19	Raised			
RENAULT	Clio IV Sporter / Grand Tourer	5	13>19	Smooth	000126700000	000134600000	KIT39G
RENAULT	Clio Stora/Campus	3	05>12	Smooth	000126700000	000134600000	KIT20G
RENAULT	Clio Stora/Campus	5	05>12	Smooth	000126700000	000134600000	KIT22G
RENAULT	Clio V	5	19>	Smooth	000126700000	000134600000	KIT48G
RENAULT	Duster I		08>13	Raised			
RENAULT	Duster I		13>18	Raised			
RENAULT	Duster II		18>24	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
RENAULT	Duster III		24>	Raised			
RENAULT	Duster Oroch		16>	Raised			
RENAULT	Espace IV		02>15				
RENAULT	Espace V	5	15>	Smooth			NA
RENAULT	Fluence		12>				
RENAULT	Gran Modus	5	07>13	Smooth	000126800000	000134700000	KIT60G
RENAULT	Grand Scenic II	5	03>08	Smooth	000126700000	000134600000	FIX201FP
RENAULT	Grand Scenic III (No tetto in vetro / No glass sunroof)	5	09>13	Smooth	000126800000	000134700000	KIT10G
RENAULT	Grand Scenic III (No tetto in vetro / No glass sunroof)	5	13>16	Smooth	000126800000	000134700000	KIT10G
RENAULT	Grand Scenic IV	5	17>	Flush			
RENAULT	Grand Scenic IV	5	17>	Smooth	000126800000	000134700000	KIT48G
RENAULT	Kadjar	5	15>	Flush			
RENAULT	Kangoo Express (Mk1)	5	98>08	Raised			
RENAULT	Kangoo Express (Mk1)	5	98>08	Smooth	000126700000	000134600000	FIX208FP
RENAULT	Kangoo Express (Mk2)	5	08>	Raised			
RENAULT	Kangoo Express (Mk2)	5	08>	Smooth	000126800000	000134700000	FIX208FP
RENAULT	Koleos	5	08>16	Raised			
RENAULT	Koleos	5	17>	Flush			
RENAULT	Koleos	5	08>16	Smooth	000126800000	000134700000	KIT02G
RENAULT	Laguna I		93>01				
RENAULT	Laguna I Station Wagon		96>01	Raised			
RENAULT	Laguna II	4	00>08	Smooth	000126700000	000134600000	KIT17G
RENAULT	Laguna II Sportour		00>08	Raised			
RENAULT	Laguna III	5	08>	Smooth	000126700000	000134600000	KIT02G
RENAULT	Laguna III Coupé		08>				
RENAULT	Laguna III Sportour		08>	Raised			
RENAULT	Megane CC		10>				
RENAULT	Megane Coupe		96>03				
RENAULT	Megane Coupé		08>				
RENAULT	Megane I		95>03				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
RENAULT	Megane I Station Wagon	5	95>03	Smooth	000126700000	000134600000	KIT61G
RENAULT	Megane II	5	02>10	Smooth	000126700000	000134600000	FIX201FP
RENAULT	Megane II Sportour		02>10	Raised			
RENAULT	Megane III	5	08>16	Smooth	000126700000	000134600000	KIT48G
RENAULT	Megane III Coupé	3	09>	Smooth	000126800000	000134700000	KIT10G
RENAULT	Megane III Sportour	5	09>16	Raised			
RENAULT	Megane III Sportour (No tetto in vetro / No glass sunroof)	5	09>16	Smooth	000126700000	000134600000	KIT48G
RENAULT	Megane IV	5	16>	Smooth	000126800000	000134700000	KIT26G
RENAULT	Megane IV Grand Coupé	4	17>	Smooth	000126800000	000134700000	KIT48G
RENAULT	Megane IV Sporter		16>	Flush			
RENAULT	Megane E-Tech Eletic	5	21>	Smooth	000126800000	000134700000	KIT02G
RENAULT	Megane Scenic	5	97>99	Smooth	000126700000	000134600000	KIT23G
RENAULT	Modus	5	04>13	Smooth	000126800000	000134700000	KIT60G
RENAULT	R5	5	24>	Smooth	000126800000	000134700000	KIT45G
RENAULT	Rafale	5	24>	Smooth	000126800000	000134700000	KIT39G
RENAULT	Safrane		92>00				
RENAULT	Sandero Stepway		08>	Raised			
RENAULT	Scenic I		99>03				
RENAULT	Scenic II	5	03>08	Smooth	000126700000	000134600000	FIX201FP
RENAULT	Scenic III	5	13>16	Raised			
RENAULT	Scenic III (No tetto in vetro / No glass sunroof)	5	09>13	Smooth	000126800000	000134700000	KIT10G
RENAULT	Scenic III (No tetto in vetro / No glass sunroof)	5	13>16	Smooth	000126800000	000134700000	KIT10G
RENAULT	Scenic IV	5	17>	Smooth	000126800000	000134700000	KIT48G
RENAULT	Scenic X Mod	5	09>13	Smooth	000126800000	000134700000	KIT48G
RENAULT	Scenic X Mod	5	13>16	Raised			
RENAULT	Scenic X Mod	5	13>16	Smooth	000126800000	000134700000	KIT27G
RENAULT	Scenic X Mod Cross		13>16	Raised			
RENAULT	Symbioz	5	24>	Smooth	000126800000	000134700000	KIT41G
RENAULT	Talisman	4	15>	Smooth	000126800000	000134700000	KIT36G
RENAULT	Talisman Sporter	5	16>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
RENAULT	Trafic (X83) Combi		01>14				
RENAULT	Twingo I		93>07				
RENAULT	Twingo II	3	07>13	Smooth	000126700000	000134600000	KIT25G
RENAULT	Twingo III	5	14>	Smooth	000126800000	000134700000	KIT39G
RENAULT	Zoe	3	13>	Smooth			NA
RENAULT	Zoe	5	12>	Smooth			NA
ROVER	25		99>05				
ROVER	45	4	99>05	Smooth	000126700000	000134600000	KIT17G
ROVER	75	4	99>05	Smooth			NA
ROVER	600		93>99				
ROVER	200 Tourer		92>99				
ROVER	75 Tourer		00>05	Raised			
ROVER	Streetwise		04>05	Raised			
SAAB	900	5	91>97	Smooth	000126700000	000134600000	KIT54G
SAAB	9-3	4	02>13	Smooth			NA
SAAB	9-3		98>02				
SAAB	9-5	4	97>12	Smooth	000126700000	000134600000	KIT54G
SAAB	9-3 Cabrio		02>13				
SAAB	9-3 SportHatch	5	02>13	Raised			
SAAB	9-3 SportHatch	5	02>13	Smooth			NA
SAAB	9-3 X		09>13	Raised			
SAAB	9-4 X		10>11	Raised			
SAAB	9-5 Station Wagon		99>12	Raised			
SAAB	9-7 X		04>09	Raised			
SAIC	Maxus T90 Ev	4	21>	Smooth	000126800000	000134700000	KIT17G
SEAT	Alhambra (7M)		96>10	Raised			
SEAT	Alhambra (7N)		10>15	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SEAT	Alhambra (7N)		15>	Raised			
SEAT	Altea		09>				
SEAT	Altea	5	04>09	Smooth	000126700000	000134600000	KIT10G
SEAT	Altea XL		07>09	Flush			
SEAT	Altea XL		09>	Flush			
SEAT	Arona		17>	Raised			
SEAT	Ateca	5	16>	Raised			
SEAT	Ateca	5	16>	Smooth	000126800000	000134700000	KIT66G
SEAT	Córdoba I	4	93>02	Smooth	000126700000	000134600000	KIT61G
SEAT	Córdoba II	4	02>09	Smooth	000126700000	000134600000	KIT29G
SEAT	Córdoba II Vario		96>02				
SEAT	Exeo		08>13				
SEAT	Exeo ST		09>13	Raised			
SEAT	Ibiza II		93>02	Smooth	000126700000	000134600000	KIT61G
SEAT	Ibiza III	5	02>09	Smooth	000126700000	000134600000	KIT29G
SEAT	Ibiza IV	5	08>17	Smooth	000126800000	000134700000	KIT03G
SEAT	Ibiza IV Cupra		09>16				
SEAT	Ibiza IV SC	3	08>16	Smooth	000126700000	000134600000	KIT05G
SEAT	Ibiza IV ST		10>16	Flush			
SEAT	Ibiza V	5	17>	Smooth	000126800000	000134700000	KIT72G
SEAT	Leon I (1M)		99>05				
SEAT	Leon II (1P)	4	05>09	Smooth	000126700000	000134600000	KIT10G
SEAT	Leon II (1P)	4	09>13	Smooth	000126700000	000134600000	KIT10G
SEAT	Leon III (5F)	5	12>20	Smooth	000126800000	000134700000	KIT46G
SEAT	Leon III (5F) SC	3	12>20	Smooth			
SEAT	Leon III (5F) ST	5	12>20	Flush			
SEAT	Leon III (5F) X-Perience ST	5	15>20	Flush			
SEAT	Leon IV (MK4) (No tetto in vetro / No glass sunroof)	5	20>	Smooth	000126800000	000134700000	KIT02G
SEAT	Leon IV (MK4) Sporturer (No tetto in vetro / No glass sunroof)	5	20>	Flush			
SEAT	Mii	3	12>21	Smooth	000126800000	000134700000	KIT10G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SEAT	Mii	5	12>21	Smooth	000126800000	000134700000	KIT51G
SEAT	Tarraco	5	18>	Raised			
SEAT	Tarraco	5	18>	Smooth	000126800000	000134700000	KIT02G
SEAT	Toledo	5	11>	Smooth	000126800000	000134700000	KIT03G
SEAT	Toledo		91>99				
SEAT	Toledo		98>05				
ŠKODA	Citigo	3	12>	Smooth	000126800000	000134700000	KIT10G
ŠKODA	Citigo	5	12>	Smooth	000126800000	000134700000	KIT10G
ŠKODA	Enyaq	5	20>	Flush			
ŠKODA	Enyaq Coupè	5	22>	Smooth	000126800000	000134700000	KIT48G
ŠKODA	Fabia I (6Y)		99>07				
ŠKODA	Fabia I (6Y) Wagon		99>07	Raised			
ŠKODA	Fabia II (5J)	5	07>14	Smooth	000126700000	000134600000	KIT35G
ŠKODA	Fabia II (5J) Wagon / Break		07>14	Raised			
ŠKODA	Fabia III (NJ) (No tetto in vetro / No glass sunroof)	5	15>22	Smooth	000126700000	000134600000	KIT03G
ŠKODA	Fabia III (NJ) Wagon / Break		15>22	Raised			
ŠKODA	Fabia III (NJ) Wagon / Break		15>22	Smooth	000126700000	000134600000	KIT02G
ŠKODA	Fabia Scout		09>14	Raised			
ŠKODA	Felicia	4	94>01	Smooth	000126700000	000134600000	KIT17G
ŠKODA	Felicia Station Wagon		94>01	Raised			
ŠKODA	Forman		90>95	Raised			
ŠKODA	Justy		98>02				
ŠKODA	Kamiiq	5	19>23	Raised			
ŠKODA	Kamiiq	5	24>	Raised			
ŠKODA	Karoq		18>	Raised			
ŠKODA	Kodiaq		17>21	Raised			
ŠKODA	Kodiaq		21>23	Raised			
ŠKODA	Kodiaq	5	24>	Flush			
ŠKODA	Legacy		98>				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
ŠKODA	Octavia (1U)	4	96>10				
ŠKODA	Octavia (1U) Wagon		96>11	Raised			
ŠKODA	Octavia II (1Z)	4	04>08	Smooth	000126700000	000134600000	KIT01G
ŠKODA	Octavia II (1Z)	5	08>13	Smooth	000126700000	000134600000	KIT02G
ŠKODA	Octavia II (1Z) Wagon	5	04>13	Raised			
ŠKODA	Octavia III (5E)	4	13>	Smooth	000126800000	000134700000	KIT03G
ŠKODA	Octavia III (5E) Wagon	5	13>20	Raised			
ŠKODA	Octavia IV (NX)	4	20>	Smooth	000126800000	000134700000	KIT03G
ŠKODA	Octavia IV (NX) Wagon	5	20>	Flush			
ŠKODA	Octavia Scout		07>	Raised			
ŠKODA	Praktik		06>15	Raised			
ŠKODA	Rapid (NH3)	4	12>	Smooth	000126700000	000134600000	KIT02G
ŠKODA	Rapid (NH1) Spaceback	5	13>	Smooth	000126800000	000134700000	KIT03G
ŠKODA	Roomster		06>15	Raised			
ŠKODA	Roomster		06>15	Smooth			NA
ŠKODA	Scala	5	19>	Smooth	000126800000	000134700000	KIT48G
ŠKODA	Scala	5	24>	Smooth	000126800000	000134700000	KIT94G
ŠKODA	Superb (3T)	4	08>13	Smooth	000126800000	000134700000	KIT29G
ŠKODA	Superb (3T) Wagon		10>13	Raised			
ŠKODA	Superb (3T) Wagon		13>15	Raised			
ŠKODA	Superb (3U)	4	01>08	Smooth	000126700000	000134600000	KIT35G
ŠKODA	Superb (3V)	4	15>	Smooth	000126800000	000134700000	KIT03G
ŠKODA	Superb (3V) Wagon	5	15>	Raised			
ŠKODA	Superb (3V) Wagon	5	15>23	Smooth	000126800000	000134700000	KIT03G
ŠKODA	Superb (3V) Wagon	5	24>	Flush			
ŠKODA	Yeti (5L)/Yeti Outdoor		09>17	Raised			
SSANGYONG	Actyon	5	05>10	Smooth	000126800000	000134700000	KIT08G
SSANGYONG	Actyon Sports	4	07>18	Smooth	000126800000	000134700000	KIT52G
SSANGYONG	Korando		97>05	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SSANGYONG	Korando (C200)		10>19	Raised			
SSANGYONG	Korando	5	19>	Raised			
SSANGYONG	Korando	5	19>	Smooth	000126800000	000134700000	KIT19G
SSANGYONG	Kyron		05>14	Raised			
SSANGYONG	Musso		96>05	Raised			
SSANGYONG	Rexton (Y200)		01>06	Raised			
SSANGYONG	Rexton II (Y250)		06>12	Raised			
SSANGYONG	Rexton Sport (Y400) / Musso (Q200)	4	17>	Raised			
SSANGYONG	Rexton Sport (Y400) / Musso (Q200)	4	17>	Smooth	000126800000	000134700000	KIT02G
SSANGYONG	Rexton W (Y290)		13>17	Raised			
SSANGYONG	Rexton sport XL	4	23>	Smooth	000126800000	000134700000	KIT78G
SSANGYONG	Rexton sport XL	4	23>	Raised			
SSANGYONG	Rexton	5	23>	Raised			
SSANGYONG	Rodius		04>13	Raised			
SSANGYONG	Tivoli	5	15>	Smooth	000126700000	000134600000	KIT35G
SSANGYONG	Tivoli	5	15>	Flush			
SSANGYONG	Tivoli	5	15>	Smooth	000126700000	000134600000	KIT35G
SSANGYONG	Torres (J100)	5	22>	Flush			
SSANGYONG	XLV	5	16>	Raised			
SSANGYONG	XLV	5	16>	Smooth	000126800000	000134700000	KIT67G
SUBARU	Ascent	5	18>	Raised			
SUBARU	BRZ		12>				NA
SUBARU	Crosstreck	5	11>	Raised			
SUBARU	Crosstreck	5	11>	Smooth	000126700000	000134600000	FIX202FP
SUBARU	Forester (SG)		03>08				
SUBARU	Forester (SH)		08>13	Raised			
SUBARU	Forester (SJ)		13>18	Raised			
SUBARU	Forester (SK)	5	19>	Raised			
SUBARU	Impreza V (GK) Sedan	4	16>	Smooth	000126800000	000134700000	FIX202FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SUBARU	Impreza (GC)		92>00				
SUBARU	Impreza (GD)		00>07				
SUBARU	Impreza (GF) Wagon		92>00	Raised			
SUBARU	Impreza (GG) Wagon		00>07	Raised			
SUBARU	Impreza (GH)		07>11				
SUBARU	Impreza V (GT) Hatchback	5	16>	Smooth	000126800000	000134700000	FIX202FP
SUBARU	Justy		07>	Raised			
SUBARU	Legacy (BC)	4	93>98				
SUBARU	Legacy (BG/BK) Wagon	5	93>98	Raised			
SUBARU	Legacy V (BM)	4	09>14				
SUBARU	Legacy V (BR) Station Wagon	5	09>14	Raised			
SUBARU	Levorg	5	14>	Smooth	000126700000	000134600000	FIX202FP
SUBARU	Outback III		98>09				
SUBARU	Outback IV		09>14	Flush			
SUBARU	Outback V	5	15>	Flush			
SUBARU	Outback V	5	15>	Smooth	000126800000	000134700000	KIT49G
SUBARU	Pleo	5	07>	Smooth	000126700000	000134600000	KIT02G
SUBARU	Trezia	5	11>	Smooth	000126800000	000134700000	KIT19G
SUBARU	Tribeca		05>14	Raised			
SUBARU	WRX STI	4	17>	Smooth	000126800000	000134700000	KIT66G
SUBARU	WRX STI		10>16				
SUBARU	WRX V (GK)	4	16>	Smooth	000126800000	000134700000	FIX202FP
SUBARU	XV	5	11>	Raised			
SUBARU	XV	5	11>	Smooth	000126700000	000134600000	FIX202FP
SUBARU	XV	5	22>	Raised			
SUZUKI	Across	5	20>	Flush			
SUZUKI	Across	5	20>	Flush			
SUZUKI	Alto (HA12)		98>04				
SUZUKI	Alto (HA25)	5	08>14	Smooth	000126700000	000134600000	KIT17G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SUZUKI	Baleno	5	15>19	Smooth	000126700000	000134600000	KIT65G
SUZUKI	Baleno	5	19>	Smooth	000126700000	000134600000	KIT37G
SUZUKI	Baleno		95>02	Raised			
SUZUKI	Celerio	5	15>	Smooth	000126800000	000134700000	KIT17G
SUZUKI	Dzire III	5	17>	Smooth	000126700000	000134600000	KIT76G
SUZUKI	Ertiga II (NC)	5	18>	Smooth	000126800000	000134700000	KIT75G
SUZUKI	Esteem		98>	Raised			
SUZUKI	Forenza (J200)		02>09	Raised			
SUZUKI	Grand Vitara / Escudo (JT)	5	05>17				
SUZUKI	Grand Vitara / Grande Escudo (FT/GT)	5	98>05	Raised			
SUZUKI	Ignis		16>	Raised			
SUZUKI	Ignis (HR)		01>07				
SUZUKI	Ignis (HT)		03>08	Raised			
SUZUKI	Jimny	3	18>	Smooth	000126800000	000134700000	KIT74G
SUZUKI	Jimny		98>12	Raised			
SUZUKI	Karimun		97>05	Raised			
SUZUKI	Kei		98>09	Raised			
SUZUKI	Kizashi		13>				
SUZUKI	Liana		01>07				
SUZUKI	Splash	5	08>	Smooth	000126700000	000134600000	KIT17G
SUZUKI	Swace	5	20>	Flush			
SUZUKI	Swace	5	20>	Smooth	000126700000	000134600000	KIT36G
SUZUKI	Swift IV		04>10				
SUZUKI	Swift V	3	10>13				
SUZUKI	Swift V	3	13>17	Smooth			NA
SUZUKI	Swift V	5	10>13	Smooth	000126700000	000134600000	KIT17G
SUZUKI	Swift V	5	13>17	Smooth	000126700000	000134600000	KIT17G
SUZUKI	Swift VI	5	17>	Smooth	000126700000	000134600000	KIT37G
SUZUKI	Sx4		06>09	Raised			
SUZUKI	Sx4		10>13	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
SUZUKI	Sx4 S-Cross	5	16>21	Flush			
SUZUKI	Sx4 S-Cross	5	13>16	Flush			
SUZUKI	Sx4 S-Cross	5	21>	Flush			
SUZUKI	Sx4 S-Cross	5	16>21	Smooth	000126800000	000134700000	KIT65G
SUZUKI	Vitara / Escudo (FT/GT)	3	98>05	Raised			
SUZUKI	Vitara / Escudo (JT)	3	05>17				
SUZUKI	Vitara / Escudo (LY)	5	15>	Flush			
SUZUKI	Vitara / Escudo (LY)	5	15>	Smooth	000126800000	000134700000	KIT08G
SUZUKI	Wagon R		93>08				
SUZUKI	Wagon R+		97>05	Raised			
SUZUKI	XL-7		98>10	Raised			
TESLA	Model 3	4	17>	Smooth			
TESLA	Model S	4	12>17	Smooth	000126800000	000134700000	FIX202FP
TESLA	Model X	5	15>				
TESLA	Model Y	4	20>	Smooth			
TOYOTA	4Runner (N280)	5	09>	Raised			
TOYOTA	Agya	5	23>	Smooth	000126700000	000134600000	KIT02G
TOYOTA	Auris / Corolla (E150)	5	06>12	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Auris / Corolla (E180)	5	12>18	Smooth	000126700000	000134600000	KIT19G
TOYOTA	Auris / Corolla (E180) Touring Sports	5	13>18	Flush			
TOYOTA	Auris / Corolla (E180) Touring Sports	5	13>18	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Auris / Corolla (E210) Hatchback	5	18>	Smooth	000126700000	000134600000	KIT36G
TOYOTA	Auris / Corolla (E210) Touring Sports	5	18>	Flush			
TOYOTA	Auris / Corolla (E210) Touring Sports	5	18>	Smooth	000126700000	000134600000	KIT36G
TOYOTA	Avalon (XX50)	4	18>	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Avanza		03>11	Raised			
TOYOTA	Avanza		11>	Raised			
TOYOTA	Avanza (W100RE)	5	22>	Smooth	000126800000	000134700000	KIT12G

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
TOYOTA	Avensis (T210)		97>03				
TOYOTA	Avensis (T210) Verso		97>03	Raised			
TOYOTA	Avensis (T210) Wagon		97>03	Raised			
TOYOTA	Avensis (T250)		03>09				
TOYOTA	Avensis (T250) Verso		03>09	Raised			
TOYOTA	Avensis (T250) Wagon		03>09	Raised			
TOYOTA	Avensis (T270)	4	09>11	Smooth	000126800000	000134700000	KIT03G
TOYOTA	Avensis (T270) Wagon	5	09>11	Smooth			NA
TOYOTA	Aygo I	5	05>14	Smooth	000126700000	000134600000	KIT17G
TOYOTA	Aygo II	5	14>21	Smooth	000126700000	000134600000	KIT17G
TOYOTA	Aygo X	5	21>	Smooth			NA
TOYOTA	Caldina		02>07	Raised			
TOYOTA	Camry		91>01	Raised			
TOYOTA	Camry (XV70)	4	17>	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Carib		07>	Raised			
TOYOTA	C-HR	5	16>	Smooth	000126800000	000134700000	KIT38G
TOYOTA	C-HR	5	23>	Smooth	000126800000	000134700000	KIT04G
TOYOTA	Corolla (E120) Sedan	4	00>17	Smooth	000126700000	000134600000	KIT19G
TOYOTA	Corolla (E120) Station Wagon		02>05	Raised			
TOYOTA	Corolla (E210) Sedan	4	18>	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Corolla Fielder		04>09	Raised			
TOYOTA	Corolla Verso	5	00>04	Raised			
TOYOTA	Corolla Verso	5	04>07	Raised			
TOYOTA	Corolla Verso	5	00>04	Smooth	000126800000	000134700000	KIT21G
TOYOTA	Corolla Verso	5	04>07	Smooth	000126800000	000134700000	KIT35G
TOYOTA	Corolla Cross (XG10)	5	22>	Flush	NA	NA	NA
TOYOTA	Corolla Cross (XG10)	5	20>	Smooth			
TOYOTA	Estima		00>02	Raised			
TOYOTA	Estima		03>05	Raised			
TOYOTA	Etios Cross		14>	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
TOYOTA	FJ Cruiser		07>14	Raised			
TOYOTA	Fortuner		04>15	Raised			
TOYOTA	Fun Cargo		99>05	Raised			
TOYOTA	Gracia		97>02	Raised			
TOYOTA	GT86		12>				
TOYOTA	Highlander (XU20)		00>08	Raised			
TOYOTA	Highlander (XU40)		07>14	Raised			
TOYOTA	Highlander III (XU50)	5	13>19				
TOYOTA	Hilux (AN130)	5	15>	Smooth	000126800000	000134700000	KIT13G
TOYOTA	Hilux (AN30)	4	11>15	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Hilux Sport Rider		98>04	Raised			
TOYOTA	Hilux sw4		06>15	Raised			
TOYOTA	Ipsium		01>03	Raised			
TOYOTA	Ipsium		96>00	Raised			
TOYOTA	iQ		09>				
TOYOTA	Kluger Grande		00>13	Raised			
TOYOTA	Land Cruiser (J100)	5	98>07	Raised			
TOYOTA	Land Cruiser (J200)	5	07>21	Raised			
TOYOTA	Land Cruiser (J200)	5	07>21	Smooth			NA
TOYOTA	Land Cruiser (J300)	5	21>	Raised			
TOYOTA	Land Cruiser	5	24>	Raised			
TOYOTA	Matrix (E130)	5	03>08				
TOYOTA	Passo (M300)	5	05>11	Smooth	000126800000	000134700000	KIT17G
TOYOTA	Picnic		95>01	Raised			
TOYOTA	Prado		02>09	Raised			
TOYOTA	Prado		09>	Raised			
TOYOTA	Previa II		00>05	Raised			
TOYOTA	Prius +	5	12>15	Smooth	000126800000	000134700000	KIT03G
TOYOTA	Prius + / Prius v / Prius α	5	15>	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Prius c	5	15>				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
TOYOTA	Prius III (XW30)	5	09>15	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Prius IV (XW50)	5	15>18	Smooth	000126800000	000134700000	KIT36G
TOYOTA	Prius IV (XW50)	5	18>	Smooth	000126800000	000134700000	KIT36G
TOYOTA	Prius V (XW60)	4	22>	Smooth	000126900000	000134800000	KIT03G
TOYOTA	ProAce City (K0)	3	18>	Smooth	000126800000	000134700000	FIX207FP
TOYOTA	ProAce City Verso (K0)	5	18>	Raised			
TOYOTA	ProAce City Verso (K0)	5	18>	Smooth	000126800000	000134700000	FIX207FP
TOYOTA	Ractis / Verso S (XP120)	5	10>17	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Raize	5	21>	Smooth	000126700000	000134600000	KIT68G
TOYOTA	Raum		97>02	Raised			
TOYOTA	Rav 4 (XA20)		00>05	Raised			
TOYOTA	Rav 4 (XA30)	5	05>12	Raised			
TOYOTA	Rav 4 (XA30)	5	05>12	Smooth	000126800000	000134700000	KIT35G
TOYOTA	Rav 4 (XA40)	5	13>18	Raised			
TOYOTA	Rav 4 (XA40)	5	13>18	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Rav 4 (XA50)	5	18>	Flush			
TOYOTA	Rav 4 (XA50)	5	18>	Flush			
TOYOTA	Rav 4 (XA50)	5	18>	Raised			
TOYOTA	Revo III		03>05	Raised			
TOYOTA	Rush II (F800)	5	17>	Flush			
TOYOTA	Rush II (J200/F700)		06>17	Raised			
TOYOTA	Rush (F800/F850)	5	18>	Flush			
TOYOTA	Sequoia		01>07	Raised			
TOYOTA	Sequoia (XK60)	2	07>	Raised			
TOYOTA	Sienna (XL20)		03>09	Raised			
TOYOTA	Sienna (XL30)	5	10>	Flush			
TOYOTA	Sienna (XL30)		10>	Raised			
TOYOTA	Spacio		97>00	Raised			
TOYOTA	Sprinter SW		98>	Raised			
TOYOTA	Starlet		96>99				

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
TOYOTA	Tacoma III (N300) Access Cab	2	15>	Smooth	000126800000	000134700000	KIT04G
TOYOTA	Tacoma III (N300) Double Cab	4	15>	Smooth	000126800000	000134700000	KIT04G
TOYOTA	Tundra (XK50) Crew Max	4	14>	Smooth	000126900000	000134800000	KIT19G
TOYOTA	Tundra (XK50) Double Cab	2	14>	Smooth	000126900000	000134800000	KIT19G
TOYOTA	Urban Cruiser	5	09>	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Venza (AV10)	5	08>17	Smooth	000126800000	000134700000	KIT78G
TOYOTA	Verso	5	09>18	Raised			
TOYOTA	Verso	5	09>18	Smooth	000126800000	000134700000	KIT19G
TOYOTA	Yaris Cross (XP210)	5	20>	Smooth	000126700000	000134600000	KIT76G
TOYOTA	Yaris Cross (XP210)	5	20>	Flush			
TOYOTA	Yaris / Vitz (P1) Verso		00>05	Raised			
TOYOTA	Yaris / Vitz (P1)	5	99>05	Smooth	000126700000	000134600000	KIT17G
TOYOTA	Yaris / Vitz (XP130)	5	11>19	Smooth	000126700000	000134600000	KIT17G
TOYOTA	Yaris / Vitz (XP9)	5	05>11	Smooth	000126700000	000134600000	KIT17G
TOYOTA	Yaris / Vitz (XP210)	4	20>	Smooth	000126700000	000134600000	KIT17G
VOLKSWAGEN	Amarok	4	10>22	Smooth	000126800000	000134700000	FIX203FP
VOLKSWAGEN	Amarok	4	22>	Smooth	000126800000	000134700000	KIT76G
VOLKSWAGEN	Arteon	4	17>	Smooth			NA
VOLKSWAGEN	Atlas	5	19>	Raised			
VOLKSWAGEN	Beetle/Maggiolino	2	11>				
VOLKSWAGEN	Bora Variant		99>05	Raised			
VOLKSWAGEN	Caddy (2K) / Caddy (2K) Maxi		03>21	Raised			
VOLKSWAGEN	Caddy (2K) / Caddy (2K) Maxi		03>21	Smooth			NA
VOLKSWAGEN	Caddy (2K) Life / Maxi Life / Panel	5	10>15	Raised			
VOLKSWAGEN	Caddy (2K) Life / Maxi Life / Panel	5	15>21	Raised			
VOLKSWAGEN	Caddy (2K) Life / Maxi Life / Panel	5	10>15	Smooth	000126700000	000134600000	FIX208FP
VOLKSWAGEN	Caddy (2K) Life / Maxi Life / Panel	5	15>21	Smooth	000126700000	000134600000	FIX208FP
VOLKSWAGEN	Caddy (SB)	5	21>	Raised			
VOLKSWAGEN	Caddy (SB)	5	21>	Smooth	000126800000	000134700000	FIX208FP

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLKSWAGEN	California (T5)		03>15				
VOLKSWAGEN	California (T6)		16>				
VOLKSWAGEN	Caravelle (T6)		15>	Smooth	000126800000	000134700000	FIX207FP
VOLKSWAGEN	CC		12>				
VOLKSWAGEN	Cross Up!		13>	Raised			
VOLKSWAGEN	E Up!	5	14>	Smooth	000126800000	000134700000	KIT10G
VOLKSWAGEN	Eos		11>				
VOLKSWAGEN	Fox / Lupo (5Z)	3	05>11				
VOLKSWAGEN	Fox / Lupo (5Z)	5	05>11				
VOLKSWAGEN	Golf III (1H)	3	91>99	Smooth			NA
VOLKSWAGEN	Golf III (1H)	5	91>99	Smooth			NA
VOLKSWAGEN	Golf IV (1J)	3	97>04	Smooth	000126700000	000134600000	KIT63G
VOLKSWAGEN	Golf IV (1J)	5	97>04	Smooth	000126700000	000134600000	KIT62G
VOLKSWAGEN	Golf IV (1J) Variant	5	97>04	Raised			
VOLKSWAGEN	Golf V (1K)	3	03>08	Smooth	000126800000	000134700000	KIT30G
VOLKSWAGEN	Golf V (1K)	5	03>08	Smooth	000126800000	000134700000	KIT29G
VOLKSWAGEN	Golf V (1K) Cross		06>10	Raised			
VOLKSWAGEN	Golf V (1K) Plus	5	03>08	Raised			
VOLKSWAGEN	Golf V (1K) Plus	5	03>08	Smooth	000126700000	000134600000	KIT08G
VOLKSWAGEN	Golf V (1K) Variant		03>08	Raised			
VOLKSWAGEN	Golf VI (5K)	5	08>12	Smooth	000126800000	000134700000	KIT29G
VOLKSWAGEN	Golf VI (5K) Cabrio		11>14				
VOLKSWAGEN	Golf VI (5K) Cross		10>14	Raised			
VOLKSWAGEN	Golf VI (5K) GTI / GTD / GTE	5	08>12	Smooth	000126800000	000134700000	KIT29G
VOLKSWAGEN	Golf VI (5K) Plus		08>12	Raised			
VOLKSWAGEN	Golf VI (5K) Variant		08>12	Raised			
VOLKSWAGEN	Golf VII (5G)	5	12>19	Smooth	000126800000	000134700000	KIT48G
VOLKSWAGEN	Golf VII (5G) GTI / GTD / GTE	5	12>19	Smooth	000126800000	000134700000	KIT48G
VOLKSWAGEN	Golf VII (5G) Plus		13>19	Raised			
VOLKSWAGEN	Golf VII (5G) Sport Van	5	14>19	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLKSWAGEN	Golf VII (5G) Sport Van	5	14>19	Smooth	NA	NA	NA
VOLKSWAGEN	Golf VII (5G) Variant		13>19	Raised			
VOLKSWAGEN	Golf VIII	5	19>	Smooth	000126800000	000134700000	KIT48G
VOLKSWAGEN	Golf VIII Variant/Golf VIII Estate/Golf VIII Variant Alltrak	5	20>	Raised			
VOLKSWAGEN	Gran Lavidia		13>17	Raised			
VOLKSWAGEN	Id Buzz	5	22>	Smooth			
VOLKSWAGEN	Id 3	5	19>	Smooth	NA	NA	NA
VOLKSWAGEN	Id 4	5	21>	Flush			
VOLKSWAGEN	Id 5	5	22>	Smooth			
VOLKSWAGEN	Id 7	5	24>	Flush			
VOLKSWAGEN	Jetta (A4) / Bora	4	98>05	Smooth	000126700000	000134600000	KIT62G
VOLKSWAGEN	Jetta (A4) / Bora Station Wagon		98>05	Raised			
VOLKSWAGEN	Jetta (A6/5C6)	4	11>18	Smooth	000126800000	000134700000	KIT52G
VOLKSWAGEN	Jetta Variant		08>	Raised			
VOLKSWAGEN	New Beetle		97>10				
VOLKSWAGEN	Parati II		94>13	Raised			
VOLKSWAGEN	Passat (B5) Variant		96>05	Raised			
VOLKSWAGEN	Passat (B6) Variant		05>10	Raised			
VOLKSWAGEN	Passat (B7)		11>14				
VOLKSWAGEN	Passat (B7) Alltrack		12>14	Raised			
VOLKSWAGEN	Passat (B7) Variant		11>14	Raised			
VOLKSWAGEN	Passat (B8)	4	14>	Smooth	000126800000	000134700000	KIT36G
VOLKSWAGEN	Passat (B8) Alltrack	5	14>18	Raised			
VOLKSWAGEN	Passat (B8) Alltrack	5	19>	Flush			
VOLKSWAGEN	Passat (B8) Alltrack	5	19>	Smooth	000126800000	000134700000	KIT02G
VOLKSWAGEN	Passat (B8) Alltrack	5	14>18	Smooth	000126800000	000134700000	KIT69G
VOLKSWAGEN	Passat (B8) Variant	5	14>	Flush			
VOLKSWAGEN	Passat	5	24>	Flush			
VOLKSWAGEN	Phaeton		02>06				
VOLKSWAGEN	Pointer II		94>13	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLKSWAGEN	Polo III (6N)		95>99	Smooth	000126700000	000134600000	KIT64G
VOLKSWAGEN	Polo III (6N) Variant		95>99	Raised			
VOLKSWAGEN	Polo III (6N2)		99>03	Smooth	000126700000	000134600000	KIT64G
VOLKSWAGEN	Polo III (6N2) Classic		99>03				
VOLKSWAGEN	Polo III (6N2) Variant		99>03	Raised			
VOLKSWAGEN	Polo IV (9N)	5	03>08	Smooth			NA
VOLKSWAGEN	Polo IV (9N3) Cross/Polo IV (9N3) Fun		03>08	Raised			
VOLKSWAGEN	Polo V (6R/6C)	3	09>17	Smooth	000126700000	000134600000	KIT28G
VOLKSWAGEN	Polo V (6R/6C)	5	09>17	Smooth	000126700000	000134600000	KIT29G
VOLKSWAGEN	Polo V (6R/6C) Cross		09>17	Raised			
VOLKSWAGEN	Polo VI (AW)	5	17>21	Smooth	000126700000	000134600000	KIT84G
VOLKSWAGEN	Polo VI (AE1)	5	21>	Smooth	000126700000	000134600000	KIT84G
VOLKSWAGEN	Quantum		91>	Raised			
VOLKSWAGEN	Saveiro		10>	Raised			
VOLKSWAGEN	Scirocco		08>				
VOLKSWAGEN	Sharan (7M1A)		99>04	Raised			
VOLKSWAGEN	Sharan (7M1B)		03>09	Raised			
VOLKSWAGEN	Sharan (7N)		10>	Raised			
VOLKSWAGEN	Sportsvan (Mk7)		06>19	Raised			
VOLKSWAGEN	Suran / SpaceFox / CrossFox / SpaceCross (5Z)	5	05>11	Raised			
VOLKSWAGEN	Taigo/Nivus	5	21>	Smooth	000126800000	000134700000	KIT83G
VOLKSWAGEN	Taigo/Nivus	5	21>	Raised			
VOLKSWAGEN	T-Cross (1C)	5	18>	Raised			
VOLKSWAGEN	T-Cross (1C)	5	18>	Smooth	000126800000	000134700000	KIT02G
VOLKSWAGEN	T-Cross	5	24>	Raised			
VOLKSWAGEN	Tiguan (5N)	5	07>11	Raised			
VOLKSWAGEN	Tiguan (5N)		11>16	Raised			
VOLKSWAGEN	Tiguan (5N)	5	07>11	Smooth	000126800000	000134700000	KIT36G
VOLKSWAGEN	Tiguan (5N) Cross		14>	Raised			
VOLKSWAGEN	Tiguan II (AD1)	5	16>	Raised			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLKSWAGEN	Tiguan II (AD1)	5	16>	Smooth	000126800000	000134700000	KIT19G
VOLKSWAGEN	Tiguan II (AD1) Allspace	5	16>	Raised			
VOLKSWAGEN	Tiguan II (AD1) R-line	5	16>	Raised			
VOLKSWAGEN	Tiguan II (AD1) R-line	5	16>	Smooth	000126800000	000134700000	KIT19G
VOLKSWAGEN	Tiguan	5	24>	Raised			
VOLKSWAGEN	Touareg (7L)		02>06	Raised			
VOLKSWAGEN	Touareg II (7P)	5	10>13	Raised			
VOLKSWAGEN	Touareg II (7P)	5	14>18	Raised			
VOLKSWAGEN	Touareg II (7P)	5	10>13	Smooth	000126900000	000134800000	KIT08G
VOLKSWAGEN	Touareg III	5	18>	Flush			
VOLKSWAGEN	Touareg III	5	18>	Smooth	000126800000	000134700000	KIT02G
VOLKSWAGEN	Touran I (1T)	5	03>10	Raised			
VOLKSWAGEN	Touran I (1T)	5	10>15	Raised			
VOLKSWAGEN	Touran I (1T)	5	03>10	Smooth	000126800000	000134700000	KIT29G
VOLKSWAGEN	Touran I (1T)	5	10>15	Smooth	000126800000	000134700000	KIT29G
VOLKSWAGEN	Touran II (5T)	5	15>	Raised			
VOLKSWAGEN	Touran II (5T)	5	15>	Smooth	000126800000	000134700000	KIT19G
VOLKSWAGEN	Transporter / Multivan (T5)		03>15	Smooth	000126900000	000134800000	FIX207FP
VOLKSWAGEN	Transporter / Multivan (T6)		15>	Smooth	000126800000	000134700000	FIX207FP
VOLKSWAGEN	T-Roc (A1)	5	18>	Raised			
VOLKSWAGEN	T-Roc (A1)	5	18>	Smooth	000126800000	000134700000	KIT19G
VOLKSWAGEN	Up!	3	11>	Smooth	000126800000	000134700000	KIT10G
VOLKSWAGEN	Up!	5	11>	Smooth	000126800000	000134700000	KIT10G
VOLVO	C30		06>12				
VOLVO	C40	5	21>	Smooth			NA
VOLVO	C40 Recharge	5	22>	Smooth	000126800000	000134700000	KIT48G
VOLVO	C70		10>13				
VOLVO	EX30	5	23>	Smooth	000126800000	000134700000	KIT47G
VOLVO	EX90	5	24>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLVO	S40		04>08				
VOLVO	S40		08>12				
VOLVO	S60	4	18>	Smooth	000126800000	000134700000	KIT48G
VOLVO	S60 (P24)	4	00>09	Smooth			NA
VOLVO	S60 (Y20)	4	10>18	Smooth	000126800000	000134700000	KIT26G
VOLVO	S70		96>00				
VOLVO	S80	4	06>16	Smooth	000126800000	000134700000	KIT26G
VOLVO	S80		98>06				
VOLVO	S90	4	16>	Smooth	000126800000	000134700000	KIT48G
VOLVO	V40	5	12>16	Smooth	000126800000	000134700000	KIT26G
VOLVO	V40	5	16>	Smooth	000126800000	000134700000	KIT26G
VOLVO	V40	5	95>12	Raised			
VOLVO	V40	5	95>12	Smooth	000126700000	000134600000	KIT19G
VOLVO	V40 Cross Country		13>	Raised			
VOLVO	V50	5	08>12	Raised			
VOLVO	V50		04>08	Raised			
VOLVO	V50	5	08>12	Smooth	000126800000	000134700000	KIT36G
VOLVO	V60	5	10>11	Smooth	000126800000	000134700000	KIT26G
VOLVO	V60	5	11>18	Flush			
VOLVO	V60	5	19>	Flush			
VOLVO	V60/V60 Cross Country	5	11>18	Smooth	000126800000	000134700000	KIT26G
VOLVO	V60/V60 Cross Country	5	19>	Smooth	000126800000	000134700000	KIT11G
VOLVO	V60 Cross Country	5	15>18	Flush			
VOLVO	V60 Plug-in		12>				
VOLVO	V70	5	07>16	Raised			
VOLVO	V70		00>07	Raised			
VOLVO	V70		96>00	Raised			
VOLVO	V70	5	07>16	Smooth	000126800000	000134700000	KIT26G
VOLVO	V90/V90 Cross Country		16>	Flush			
VOLVO	XC40		18>	Flush			

Menabo Italy - Car Application Guide.

www.CoolaLiving.ie Ireland Tel 045 831700

Roof Bars and Clamp Kits for Cars

with a Smooth Roof

Car Make	Car Model	Doors	Year	Your Roof Type	Omega Black Bars	Omega ALU Colour Bars	Your Foot Clamp Kit for your Omega Bars
VOLVO	XC60		08>13	Flush			
VOLVO	XC60		14>17	Flush			
VOLVO	XC60		17>	Flush			
VOLVO	XC70 (P2)		00>07	Raised			
VOLVO	XC70 (P24)		07>16	Raised			
VOLVO	XC90	5	02>06	Raised			
VOLVO	XC90	5	06>14	Raised			
VOLVO	XC90	5	14>	Flush			
VOLVO	XC90	5	14>	Raised			